



Required Tools:


- Mallet/Non Marring Hammer (Do not use Metal Headed Hammer)
- Cordless Drill
- #2 Square Drive bit
- 1/2" and 7/16" Wrench or Socket
- Tape Measure

Hardware:

- (8) 1/4" x 3" Bolts
- (12) 1/4" Flange Nuts
- (12) 1 1/4" screws
- (2) 5/16" x 3" Lag Bolts
- (2) 5/16" Washers
- (4) 1/4" x 2 1/2" Bolts


Parts:

- A = (1) Seat Assembly
- B = (1) Back Assembly
- C = (1) Back Leg Assembly
- D = (1) Front Leg Assembly
- E = (1) Right Arm Rest
- F = (1) Left Arm Rest
- G = (1) Adjustable Back Brace
- H = (2) Wheels



Step 1

Attach the front leg assembly (D) to the underside of the seat assembly (A) below the 5th, 6th, & 7th slat as shown with (6) 1 1/4" screws, 3 on each side.




Step 2

Position the back leg assembly (C) against the seat assembly keeping it flush with the top as shown and 7" in from the back end of the seat assembly and fasten with (6) 1 1/4" screws, 3 on each side.




Step 3

Position the right arm rest (E) against the right side of the seat assembly as shown and fasten with (4) 1/4" x 3" bolts and (4) 1/4" flange nuts. Repeat with the left arm rest (F) on left side of the seat.




Step 4

Attach the back assembly (B) to seat assembly using (2) 1/4" x 2 1/2" bolts and (2) 1/4" flange nuts, one on each side.



Step 5

Next place the adjustable back brace (G) in between the two back back supports on the rear side of the back assembly and attach it on one side using (1) 1/4" x 2 1/2" bolts and (1) flange nut, repeat on other side.



Step 6

Attach one of the wheels (H) on the outside of the back leg assembly using (1) 5/16" x 3" lag bolt and (1) 5/16" washer. NOTE: Place the washer on the bolt and thread it thru the pre-drilled hole. Do not over tighten or the wheel wont spin, repeat on other side.



Step 7

Your chaise lounge is now complete.

Thank you for purchasing from Wildridge.