



#### Required Tools:

- Mallet/Non Marring Hammer  
(Do not use Metal Headed Hammer)
- 1/2" Wrench or Socket
- #2 Square Drive bit
- Cordless Drill

#### Hardware:

- (8) 5/16" x 3 1/2" Carriage Bolts
- (8) 5/16" Flange Nuts
- (8) 2 1/2" Screws
- (4) 1 1/4" Screws
- (4) 2" Screws

#### Parts:

- A = (1) Table Top
- B = (2) Leg Assemblies
- C = (2) Braces
- D = (2) Seats



#### Step 1

Lay table top (A) upside down on a soft surface and attach one of the leg assemblies (B) with (4) 5/16" x 3 1/2" carriage bolts and (4) 5/16" flange nuts, two per leg. Repeat with the other leg assembly.



#### Step 2

To support the leg assembly, place a brace (C), turning it so the end with no holes is towards metal frame as shown, and attach with (2) 1 1/4" screws through the hole in the frame and into the brace.



#### Step 3

Next, attach the other end of the brace to the leg assembly, with (2) 2" screws, as shown. Repeat Step 2 & 3 with the other brace on the other leg assembly.



#### Step 4

Set the table up on its side, and place one of the seats into the notches provided in the frame.



#### Step 5

On the underside of the seat, fasten with (2) 2 1/2" screws by going through the block and into the frame, do the same on the other end. Repeat Steps 4 & 5 with the other seat.



Your table is now complete.... enjoy!

*Thank you for purchasing from Wildridge.*