


Required Tools:

- Mallet/Non Marring Hammer
(Do not use Metal Headed Hammer)
- 7/16" Wrench or Socket
- 1/2" Wrench or Socket

Parts:

- A = (1) Backrest
- B = (1) Seat
- C = (1) Left Facing Arm Rest
- D = (1) Right Facing Arm Rest




Hardware:

- Swing Chains
- (6) 1/4" x 2" Bolts
- (6) 1/4" Flange Nuts
- (4) 1/4" x 3 1/2" Bolts
- (4) 1/4" Washers
- (4) 1/4" Locknuts
- (2) 5/16" x 5 3/4" Eye Bolts
- (2) 5/16" x 5" Eye Bolts
- (4) 5/16" Flange Nuts
- (4) 5/16" Washers
- (4) 5/16" Lock Nuts
- (4) Connecting Links



Step 1

Attach the seat (B) to the backrest (A) where the back and seat supports meet, using (6) 1/4"x2" bolts and (6) 1/4" flange nuts.



#2:

- (1) 5/16" x 5 3/4" Eye Bolt
- (1) 5/16" Flange Nut
- (1) 5/16" Washer
- (1) 5/16" Locknut

#1:

- (2) 1/4" x 3 1/2" Bolts
- (2) 1/4" Locknuts
- (2) 1/4" Washers

#3:

- (1) 5/16" x 5" Eye Bolt
- (1) 5/16" Flange Nut
- (1) 5/16" Washer &
- (1) 5/16" Locknut

Step 2

Lay swing on its left side and attach the right facing arm rest (D) to side of the seat placing the hardware where shown in the picture above and following instructions below:

#1: Slide (2) bolts through holes provided (from the outside through the armrest into the seat), add washer and locknut and tighten.

#2: Thread flange nut onto eye bolt (with flange turned away from eye) as far as the thread allows, slide it through the hole on the back of the armrest from the outside, then through the backrest, add washer and locknut and tighten.

#3: Thread flange nut onto eye bolt (with flange turned away from eye) as far as the thread allows, then slide it through the hole on the front of the armrest, add washer and locknut and tighten.

Next, Repeat Step 2 with left facing armrest (C).



Step 3

Attach the chains to the eyebolts with the 4 connecting links, as shown. Your swing is now complete.