

#### Required Tools:


- Mallet/Non Marring Hammer  
(Do not use Metal Headed Hammer)
- Cordless Drill
- #2 Square Drive Bit
- 9/16" And 7/16" Wrench Or Socket

#### Hardware:

- (8) 1/4" X 2 3/4" Bolts
- (2) 1/4" X 2" Bolts
- (10) 1/4" Flange Nuts
- (4) 3/8" X 2 1/4" Machine Bolts
- (4) 3/8" X 2 1/2" Machine Bolts
- (8) 3/8" Lock Nuts
- (16) 3/8" Washers
- (8) 3" Screws
- (6) 2 1/2" Screws
- (4) 2" Screws
- (4) Glider Brackets

#### Parts:

- A = Back
- B = Seat
- C = Left Arm Assembly
- D = Right Arm Assembly
- E = Glider Base
- F = Angle Iron
- G = Base Support Brackets



#### Step 1

Position the back (A) onto the seat (B) as shown. Keeping the side and back flush, fasten with (3) 2 1/2" screws through the pre-drilled holes.




#### Step 2

On the back side of the swing, place the angle iron (F) onto the frame where the back and the seat meet, as shown. Fasten the angle iron to the frame with (3) 2 1/2" screws through the pre-drilled holes in the angle iron.


#### Step 3

Set the back/ seat assembly on its side as shown, and fasten the right arm assembly (D) using (4) 2 3/4" bolts in the legs and (1) 2" bolt in the arm, as shown. Put flange nuts onto the end of the bolts, but do not tighten completely. Repeat on the other side with the left arm assembly. Stand the glider up on all fours and adjust the chair so it sits evenly, tighten the flange nuts.




#### Step 4

Fasten the front slat on the seat to the legs as shown with (2) 2" screws through the pre-drilled holes. Repeat on other side.



#### Step 5

Position the glider base (E) and the base support brackets (G), as shown. Fasten the glider base to the base supports with (4) 3" screws, 2 on each side. Repeat on the other end with the other glider base.



#### Step 6

Next, to mount a glider bracket onto the glider base, slide (1) 3/8" washer onto (1) 3/8" x 2 1/2" machine bolt. Push the bolt through the pre-drilled hole in the base from the inside to the outside. Now, add another 3/8" washer, then hang a glider bracket onto the bolt with the curve facing away from the glider base, as shown. Now fasten (1) 3/8" lock nut tightly on to the bolt. Repeat on the other 3 sides.



#### Step 7

Set the seat assembly over the glider base assembly, making sure the straight part of the glider base assembly is facing towards the front and the angled part of the base is turned towards the back. Fasten the bottom of the glider hanger (to each of the legs) by sliding (1) 3/8" washer onto (1) 3/8" x 2 1/4" machine bolt. Push the bolt through hole from the inside to the outside. Now, add another 3/8" washer, then fasten (1) 3/8" lock nut tightly on to the bolt.



#### Step 8

Your glider is complete. Enjoy!

*Thank you for purchasing from Wildridge.*