



#### Required Tools:


- Mallet/Non Marring Hammer  
(Do not use Metal Headed Hammer)
- Cordless Drill
- #2 Square Drive bit
- 7/16" Wrench or Socket

#### Parts:

- A = (1) Chair Seat
- B = (1) Chair Back
- C = (2) Rockers
- D = (2) Front Legs
- E = (1) Right Arm Rest
- F = (1) Left Arm Rest


#### Hardware:

- (6) 1/4" x 2 1/4" Bolts
- (8) 1/4" Flange Nuts
- (4) 2 1/2" Screws
- (4) 4" Screws
- (8) 1 1/4" Screws
- (2) 1/4" x 2" Bolts



#### Step 1

Attach the front legs (D) onto the chair seat (A) with the support blocks facing away from the chair as shown with (4) 2 1/4" bolts & a flange nuts, two per leg.




#### Step 2

Mount the chair back (B) onto the seat (A) as shown, leaving a 3/4" gap between the last slat in the seat and the back boards, fasten with (4) 2 1/2" screws, two on each side of the seat.



#### Step 3

Lay the assembly on its side as shown, and fasten a rocker (C) on the back of the chair seat with (1) 2 1/4" bolt & a flange nut. Fasten the front of the rocker to the leg with (2) 4" screws to the bottom of leg. Repeat with other rocker on the other side.



#### Step 4

Now place armrests (E & F) as shown, fasten using (2) 2" bolts & flange nuts in back, one per arm rest. Space arm rests evenly on the top of the leg support blocks and fasten from the bottom up with (8) 1 1/4" screws, four in each arm. Your rocker is now complete.