

Required Tools:


- Hammer
- Cordless Drill
- #2 Square Drive bit
- 7/16" Wrench or Socket

Hardware:

- (8) 1/4" x 3 1/2" bolts
- (8) 1/4" Flange Nuts
- (4) 3" Screws
- (8) 2 1/2" Screws


Parts:

- A = (1) Table Top
- B = (4) Legs
- C = (2) Cross Supports
- D = (2) Braces




Step 1

Lay the table top (A) upside down on a soft surface and fasten the 4 legs (B) to the outside of the shorter cleats, using (2) 1/4"x3 1/2" bolts and (2) 1/4" flange nuts, per leg, making sure the countersink holes on the legs are facing outwards.



Step 2

Center the cross supports (C) in between the legs, as shown, where the countersink holes align, and fasten with (1) 3" screw, one per leg.



Step 3

Place the brace against the leg and table cleat so it has contact with both, making sure the countersink holes are facing outward. Fasten with (1) 2 1/2" screw into the cleat, and (1) 2 1/2" screw into the leg. Repeat with remaining three braces on the remaining three legs.



Step 4

Your table is now complete.

Thank you for purchasing from Wildridge.