

Required Tools:


- Hammer
- Cordless Drill
- #2 Square Drive Bit
- 7/16" Wrench or Socket

Parts:

- A = (1) Table Top
- B = (4) Legs
- C = (1) Shelf

Hardware:

- (8) 2 1/2" Screws
- (4) 1/4" x 3 1/2" Bolts
- (4) 1/4" Flange Nuts



Step 1

Lay table top (A) upside down on a soft surface and place the legs (B) in place, butting them up against the corner of the two stretchers, making sure all countersink holes in the legs are facing towards the outside. Fasten with (2) 2 1/2" screws per leg.



Step 2

Attach the shelf as shown (C), with (4) 1/4" x 3 1/2" bolts and (4) 1/4" flange nuts, one per leg.



Your side table is now complete.

Thank you for purchasing from Wildridge.