

#### Required Tools:


- Tape Measure
- Cordless Drill
- #2 Square Drive Bit

#### Parts:

- A = (1) Table Top
- B = (4) Legs
- C = (1) Shelf

#### Hardware:

- (12) 1 3/4" Screws



#### Step 1

Lay table top (A) upside down on a soft surface and place the legs (B) in place, butting them up against the corner of the two stretchers, fasten with (2) 1 3/4" screws per leg.



#### Step 2

Attach shelf (C) as shown (shelf needs to be flush with outside of legs). Measuring 9 3/4" to top of shelf, fasten with (4) 1 3/4" screws (1 per leg) through the pre-drilled holes provided.



Your table is now complete.

*Thank you for purchasing from Wildridge.*