

#### Required Tools:


- Cordless Drill
- #2 Square Drive Bit

#### Parts:

- A = (1) Bench Seat
- B = (4) Legs
- C = (2) Stretchers
- D = (1) Cross Brace


#### Hardware:

- (8) 2 1/2" Screws
- (6) 3" Screws



#### Step 1

Lay bench seat (A) upside down on a soft surface and fasten the leg (B) to the inside corner with (2) 2 1/2" screws, into the seat support. Repeat with remaining three legs making sure the pre-drilled holes align for step 2.



#### Step 2

Placing the stretcher (C) so the notch faces towards the center of the bench, and is straight with the legs, fasten it to the legs where the pre-drilled holes are with (2) 3" screws, one on each leg. Repeat on other end of bench.



#### Step 3

Flip the bench upright and slide the cross brace (D) into the notch on the stretcher and attach with (1) 3" screw, repeat on other end.



Your bench is now complete.

*Thank you for purchasing from Wildridge.*