

#### Required Tools:


- Mallet/Non Marring Hammer  
(Do not use Metal Headed Hammer)
- Cordless Drill
- #2 Square Drive Bit
- 7/16" Wrench Or Socket

#### Hardware:

- (6) 1/4" X 3" Bolts
- (4) 1/4" X 3 1/2" Bolts
- (2) 1/4" X 2" Bolts
- (12) 1/4" Flange Nuts
- (6) 2" Screws
- (6) 1 1/4" Screws

#### Parts:

- A = (1) Seat
- B = (2) Back Legs
- C = (2) Front Legs
- D = Backrest
- E = Footrest
- F = (2) Armrests



#### Step 1

Lay seat (A) on its side as shown. Lay one of the legs (B) into position onto the back of the seat as shown, and attach on the outside of seat with (2) 1/4" x 3" bolts and (2) 1/4" flange nuts. Repeat with the other leg on the other side.



#### Step 2

Position front legs (C) as shown and fasten to seat with (2) 1/4" X 3" bolts and (2) 1/4" flange nuts, one on each side.

Note: Make sure they are positioned as shown with arm blocks flush on front side and inside part of the legs.





**Step 3**  
Fasten backrest (D) in position shown with (6) 2" screws.



**Step 4**  
Fasten footrest (E) to legs with (4) 1/4"x3-1/2" bolts and nuts.



**Step 5**  
Fasten the back of one of the armrests (G) to the backrest with (1) 1/4"x2-1/2" bolt and (1) 1/4" flange nut. To fasten the front leg to the armrest, first divide space evenly on each side then fasten with (3) 1-1/4" screws from bottom up through pre-drilled holes. Repeat with other armrest. Your chair is now complete.