

Required Tools:

- Tape Measure
- Cordless Drill
- #2 Square Drive Bit
- #3 Square Drive Bit
- 7/16" Wrench or Socket

Hardware:

- (8) 2 1/2" Screws
- (2) 14 x 4" Screws
- (2) 2" Screws


Parts:

- A = (1) Back Assembly
- B = (2) Side Rails
- C = (1) Cross Support
- D = (1) Front Assembly
- E = (1) Seat




Step 1

On a soft surface, lay the back assembly (A) on its side. Choose one of the side rails (B), and turn it so the countersink hole in the middle of the rail faces outward, then place the end of the rail up against the leg of the backrest assembly, as pictured, center it and attach with (1) 2 1/2" screw through the pre-drilled hole in the leg. Repeat with the other side rail on the other leg.




Step 2

Now fasten the cross support (C) in between the two side rails, through the holes provided with (2) 2" screws, one on each end.



Step 3

Next fasten the front assembly (D) to both of the side rails using (2) 2 1/2" screws, through the holes provided, one per leg.



Step 4
Place the seat (E) into place between the back assembly and the front assembly, turning it so the wide end of the seat is towards the front, then fasten the seat to the two front legs, with (4) 2 1/2" screws, through the holes provided, two per leg.



Step 5
On the back of the chair, measure 14 1/2" from the bottom of the back leg to the bottom of the seat, as shown, fasten the back assembly to the seat using (1) 4" screw, repeat on the other side.



Your chair is now complete.

Thank you for purchasing from Wildridge.