

Required Tools:


- Mallet/Non Marring Hammer (Do not use Metal Headed Hammer)
- Cordless Drill
- #2 Square Drive bit
- 7/16" Wrench or Socket
- Tape Measure

Hardware:

- (8) 1/4" x 2" Bolts
- (8) 1/4" Flange Nuts
- (12) 2 1/2" Screws
- (4) 2" Screws
- (4) 1 1/4" Screws


Parts:

- A = (1) Table Top
- B = (4) Legs
- C = (2) Stretcher
- D = (1) Umbrella Board
- E = (4) Braces



Step 1

Lay table top (A) upside down on a soft surface. Next, turning the legs (B) so the countersink holes face outwards, place them on the outside of the cleats, as shown and attach with (8) 2" bolts and (8) 1/4" flange nuts, two each per leg.



Step 2

Position the stretchers (C) on their side, and center the umbrella board (D) in between the stretchers and fasten with (4) 2 1/2" screws through the pre-drilled holes provided, two on each end.



Step 3

Now position the stretcher/umbrella board assembly in between the legs and 11" from the foot of the legs, as shown. Fasten the legs to the assembly through the pre-drilled holes, with (8) 2 1/2" screws, two per leg.



Step 4

Fasten brace (E) with a 2" screw to the inside of leg where shown. Then fasten a 1 1/4" screw through the hole in the angle iron and into the other end of brace. Repeat with the other 3 braces.



Your table is now complete.... enjoy!

Thank you for purchasing from Wildridge.