

#### Required Tools:


- Mallet/Non-Marring Hammer  
(DO NOT Use Metal Headed Hammer)
- 7/16" Wrench or Socket
- Cordless Drill
- #2 Square Drive bit

#### Hardware:

- (2) 1/4" x 3 1/2" bolts
- (8) 1/4" x 2 1/4" bolts
- (10) 1/4" flange nuts
- (8) 1 1/4" screws
- (4) 2" screws


#### Parts

- A = (1) Back
- B = (1) Seat
- C = (2) Legs
- D = (1) Brace
- E = (2) Armrests



#### Step 1

Using (2) 1/4" x 2 1/4" bolts and (2) 1/4" flange nuts attach seat (B) to back (A). Repeat on other side.



#### Step 2

Using (2) 1/4" x 2 1/4" bolts and (2) 1/4" flange nuts attach legs (C) to seat, as shown. Repeat on other side.





#### Step 3

Now slide brace (D) in groove in front legs and fasten with (4) 2" screws, two on each end.




#### Step 4

Attach the armrest (E) to the back with (1) 1/4" x 3 1/2" bolts and (1) 1/4" flange nuts. Repeat on other side.



#### Step 5

On the front of the armrest measure a 3/4" overhang on the inside as shown left, fasten the armrest using (4) 1 1/4" screws in the pre-drilled holes from the bottom up. Repeat on other side.



#### Step 6

Your chair is complete... enjoy!

*Thank you for purchasing from Wildridge.*