



Required Tools:


- Mallet/Non-Marring Hammer (DO NOT Use Metal Headed Hammer)
- 7/16" Wrench or Socket

Hardware:

- (4) 1/4" x 4" bolts
- (2) 1/4" x 3 1/2" bolts
- (4) 1/4" x 3" bolts
- (4) 1/4" x 2 3/4" bolts
- (14) 1/4" flange nuts


Parts:

- A = Backrest
- B = Seat
- C = Right Facing Armrest
- D = Left Facing Armrest
- E = Footrest



Step 1

On a soft surface, lay the seat (B) on its side, position the backrest (A) inside the seat so the holes lineup. Place the right facing armrest (C) into place as shown. Fasten together using (2) 1/4" x 4" bolts for the back leg, (2) 1/4" x 3" bolts for the front leg, (1) 1/4" x 3 1/2" bolt for the arm, then add (5) 1/4" flange nuts, one per bolt. DO NOT TIGHTEN FLANGE NUTS AT THIS TIME.



Step 2

Turn chair over and put the right facing armrest (D) into place. Fasten together using (2) 1/4" x 4" bolts for the back leg, (2) 1/4" x 3" bolts for the front leg, (1) 1/4" x 3 1/2" bolt for the arm, then add (5) 1/4" flange nuts, one per bolt. Using a 7/16" wrench or socket, tighten all connecting points on both sides of chair.



Step 3

Using (4) 1/4" x 2 3/4" bolts and (4) 1/4" flange nuts attach the foot rest (E) to chair legs. Tighten using a 7/16" wrench or socket.



Step 4

Your high adirondack chair is now complete.

Thank you for purchasing from Wildridge.