

Required Tools:


- Mallet/Non Marring Hammer
(Do not use Metal Headed Hammer)
- 7/16" Wrench or Socket
- Cordless Drill
- #2 Square Drive Bit

Hardware:

- (8) 1/4" x 3" bolts
- (8) 1/4" flange nuts
- (8) 2 1/2" screws

Parts:

- A = (1) Table Top
- B = (4) Legs
- C = (1) Shelf



Step 1

Lay the table top (A) upside down on a soft surface. Fasten legs (B) to top as shown using (8) 1/4" x 3" bolts and (8) 1/4" flange nuts through the holes provided, two per leg.



Step 2

Lay table on side. Using (2) 2 1/2" screws, fasten shelf to one of the legs through the aligned holes. Repeat with remaining legs.



Your table is complete.

Thank you for purchasing from Wildridge.