

Required Tools:


- Mallet/Non Marring Hammer
(Do not use Metal Headed Hammer)
- 1/2" Wrench or Socket
- #2 Square Drive bit
- Cordless Drill

Hardware:

- (4) 5/16" x 3 1/2" Bolts
- (6) 2 1/2" Screws
- (6) 5/16" x 3" Bolts
- (2) 5/16" x 2" Bolts
- (2) 5/16" x 3" Lag Bolts
- (6) 5/16" Washers
- (12) 5/16" Flange Nuts
- (2) Swing Chains

Parts:

- A = (1) Backrest
- B = (1) Seat
- C = (1) Left Facing Armrest
- D = (1) Right Facing Armrest
- E = (1) Cross Bar




Step 1

Place the seat (B) onto a soft surface. Position the backrest (A) onto the seat, as shown. Fasten the backrest to the seat using (4) 5/16" x 3" bolts and (4) 5/16" flange nuts, two on each end, then fasten the center using (2) 5/16" x 2" bolts and (2) 5/16" flange nuts. *Note: Tap the bolts through the holes then add the flange nuts.*



Step 2

Attach the right facing armrest (C) to the side of the seat as shown, using (2) 5/16" x 3 1/2" bolts and (2) 5/16" flange nuts. Repeat with the left facing arm rest (D) on the other side.



Step 3

Lay the swing on its back and place the cross bar (E) up against the angle iron, as shown. Position the cross bar so the holes will be in the center of each of the three seat supports on the underside of the seat. Fasten the cross bar to the seat support using (6) 2 1/2" screws, 2 per support.



Step 4

To attach the armrest to side of the backrest put (1) 5/16" x 3" bolt through the last link on the shortest section of one of the chains (F), then add (1) 5/16" washer and insert it through the arm and backrest, then add (1) 5/16" flange nut.



Step 5

Insert (1) 5/16" washer onto (1) 5/16" x 3" lag bolt and insert it through the last link on the other end of chain, add (1) 5/16" washer before fastening it to the cross bar. Repeat step 4 and 5 on the other side. Your swing is now complete.

Thank you for purchasing from Wildridge.