



Large Personal Vault Instructions (Model BD1128)

Thank you for purchasing the Bulldog personal vault. To get started please read the entire instruction manual and then proceed to the "Opening the Personal Vault" section below.

Opening the Personal Vault using the key: The Personal Vault is supplied with a key to lock and unlock the vault. To open the vault, insert the key into the key lock (center of front panel). Turn it clockwise or to the right to open the lid. **Do not store your key inside of the vault!** Once the vault is unlocked you may manually raise the top lid. The top lid will automatically remain open at a 100-degree angle. Please note that the key cannot be removed while the vault is in the unlocked position. You must return the vault to the locked position to remove the key. Your key has a key code printed on the key. Please record your key code below and on the included warranty card. You will need this number to reorder any lost keys in the future.

_____ **KEY CODE**

Mounting Your Digital Vault Using the Included Security Cable: A "Security Cable Slot" has been provided on the back-left side of the vault. To install the security cable, follow the instructions below. The lid of the vault will need to be in the open and unlocked position.

1. First, loop the small end of the security cable around a stationary object and back through the large loop of the cable.
2. With the lid in the open position place the small end of the cable inside of the left rear corner of the vault. The metal stop should be resting against the inside of the "Security Cable Slot". Close the lid and return the vault to the locked position.

Key Replacement: Should the vault keys become lost or misplaced, you may order a replacement key by calling the service center at 800.843.3483. Your key code number is printed on the face of the key lock; this number will be required for key replacement. Replacement cost is \$5.00 per key plus S/H.

Warranty: Bulldog Vaults are protected by a full one-year guarantee that entitles the owner to free repair or replacement of the vault if the product failure was caused by a defective part or faulty workmanship. This guarantee lasts for one year from the date of purchase. The repair or replacement will either require the original sales receipt or the original registration. Your vault includes a registration card that must be filled out and returned to Bulldog Vaults with the serial number and original date of purchase. The serial number can be found on the back corner of the vault. Any vault returned to Bulldog Vaults must be returned using a Return Authorization number and shipped at the owner's expense. This number may be obtained by calling the service department at 800.843.3483. Any items returned to Bulldog Vaults without the said Return Authorization number may be refused and returned to the sender at their expense. Once the vault is received it will be evaluated, if the vault is deemed to be defective it will be repaired or replaced at the discretion of Bulldog Vaults.

Bulldog Vaults
830 Beauregard Street
Danville, VA 24541
800.843.3483 PH 434.793.7504 Fax