

Certificate

Inspector:

User Manual






SAFETY INSTRUCTIONS |-

Please observe the following instructions to ensure safety use:

- DO NOT attempt to replace the internal battery with anything other than authorized replacement battery by yourself.
- DO NOT operate in wet conditions, let unit dry completely before using.
- Ensure proper ventilation while in use and do not obstruct fan openings on use. Inadequate ventilation may cause damage to the power station.
- DO NOT stack anything on top of the power station in storage or in use, vibration and impact may lead to poor connection to hardware inside.
- DO NOT insert foreign objects into outputs or ventilation holes.
- DO NOT place the power station near heat sources like furnace or ambient heater.
- 7 The power station generates the same potentially lethal AC power as household wall outlet, please take carefully and keep children away from it.

General Specs



Output Specs

Input Specs



(emark chip built-in

Around 50-60 Times

Common Loads

LED Light Bulb Around 20-30 Hrs

Television Around 7-8 Hrs Electronic Tools Around 7-8 Hrs

About 3-4 Hours @24

About 7-8 Hours @12V

Refrigerator Around 6-7 Hrs

12-28V 200W

About 3-4 hours


Slow Cooker Around 2-3 Hrs

Charging

About 7-8 Hours

716Wh×DOD×n÷ (the current load power W) = available time (unit: hrs/times)

Note: DOD indicates Depth of Discharge, n indicates inverter efficiency, DOD=90%, n=90%.



716Wh Portable Power Station

User Manual

Please read this manual before use and follow its guidance. Keep this manual for future reference.

Detailed user manual please access: WWW.BLUETTI.COM

í 🕶 🗀 🕲 🥽 **V** BLUETTI

07 Type-C Port

08 USB Port

QUICK GUIDE

01 Charging Port

02 LCD Screen

User Manual


03 Wireless Charging Pad 09 DC 5521 Output Port

67890

04 LED Lamp Button 10 Cigarette Lighter Port

05 LED Lamp 11 AC Power Button

06 DC Power Button 12 AC Outlet




BLUETTI

LCD SCREEN GUIDE Attention: Screen turns off when all output turns off in 2s. Screen turns off while on standby. How to operate on power station to turn ON/OFF ECO Mode\ and change the working frequency: To Enter Settings Mode: Turn "AC" mode to the off position. Press "AC" and "DC" buttons at same time for 2 seconds to enter To Change Frequency Setting: Once in "Settings" mode, a. ECO-Mode Icon e. Alert Icon for Temperature press the "AC" button to switch frequency of the AC output ports to either 50 or 60 Hz depending on your location. f. Output Power Eco Mode: Once in "Settings" mode, press the "DC" button to turn ON / OFF the ECO mode. a. Alert Icon for Overload d. Alert Icon for Iow h. Alert Icon for Short Circuit Exit Settings Mode: Long press the "AC" and "DC" buttons at What`s In The Box

.....

User Manual



V BLUETTI