





ASSEMBLY INSTRUCTIONS

Parts Included	Tools Needed
1 - Backboard Assembly 2 - Wall Mount Brackets 4 - Extension Arms 8 - Hex Bolts 12 - Lock Nuts 4 - Wall Mounting Wood Screws 2 - Quick Release Pins	2 x 10mm Wrenches Stud Finder Drill With Phillips Screwdriver Bit Level Tape Measure Step Ladder



STEP 1

- Use 4 hex bolts and lock nuts to attach the extension arms (side with two holes) to the wall mounts.
- Tighten the nuts until there is slight resistance for the arms to rotate.



STEP 2

- Use 4 hex bolts and lock nuts to attach the other end of the extension arms to the backboard frame.
- Tighten the nuts until there is slight resistance for the arms to rotate.



STEP 3

- Insert the bolt from the rim assembly into the backboard frame.
- Secure the rim assembly to the backboard frame with 4 lock nuts

WARNING!: Damaged caused by hanging on the rim will void the warranty

STEP 1



Locate studs and make a mark 10½ inches above the highest point your player can reach

STEP 2




Use a level and tape measure to make a mark 16 inches from the first mark.

Confirm there is a stud behind

*Note: If your studs are not 16 inches apart, you may need to mount a solid board to the wall and mount your goal to the board.



STEP 3



Drill two wood screws into the marks you made. Leave about 1/4" so you can hang your goal on the screws.

STEP 4



Using the upper wall mount holes, hang the goal on the screws and finish tightening the screws with your drill.

STEP 5



Use your level to insure the wall mounting brackets are vertical.

STEP 6



Raise the backboard so you have clearance to screw in the lower wall mounting screws.