



FOUNDATIONLESS REQUIREMENTS:

- Centered on a square foot area that is free from cracks, seams, and walls.
- Reinforced concrete with Pressure of 3000 psi and Soil Pressure of 2500 psf.
- Chemical anchor bolts to withstand a minimum of 3,470 lbs. of pull out force.
- Concrete must contain wire mesh reinforcement.

CREATED BY: WISCOLIFT INC

GORBEL

600 FISHERS RUN
P.O. BOX 593
FISHERS, NY 14453-0593

MODEL NO.: TSJ150-FS-150-8-6

CAPACITY: 150
SPAN: 6'-0"
H.U.B.: 8.00 FT.

QUANTITY: 1
SHIPPING WT.: 321 LBS

DRAWN: abispr DATE: OCT 7, 2015

C.O.#: DEMOFSTSJ P/N: DEMOFSTSJ.2A

150 LB CAPACITY

NOTES:

- 1) JIB CRANE FOUNDATION REQUIREMENTS ARE BASED ON A SOIL PRESSURE OF 2500 LBS PER SQUARE FOOT. CONCRETE RECOMMENDED FOR JIB CRANE FOUNDATION IS 3000 LBS PER SQUARE INCH OF COMPRESSIVE FORCE.
- 2) DO NOT SCALE FROM THIS DRAWING.