

### TMG-FSH13A PRODUCT MANUAL

## 12'X12'PRE-BUILT HORSE STALL(BAMBOO)




#### **A WARNING**



- · Please read and understand the product manual completely before assembly.
- · Check against the parts list to make sure all parts are received
- wear proper safety goggles or other protective gears while in assembly
- Do not return the product to dealer. They are not equipped to handle your requests.

Missingparts or questions on assembly?
Please call:1-877-761-2819 or email:cs@tmgindustrial.com

#### Frame structure diagram




#### **ACCESSORIES LIST**

| TMG-FSH13A PART LIST |         |                     |          |
|----------------------|---------|---------------------|----------|
| NO.                  | PICTURE | DESCRIPTION         | QUANTITY |
| 1                    |         | Stable gates        | 1        |
| 2                    |         | Stable door         | 1        |
| 3                    |         | Forage Basket       | 1        |
| 4                    |         | Fine feed tank      | 1        |
| 5                    | 42      | Guide rails         | 1        |
| 6                    |         | Barn wheels         | 2        |
| 7                    |         | Guide rail limiters | 2        |
| 8                    |         | Swing stops         | 2        |
| 9                    |         | Chassis             | 1        |
| 10                   |         | Connecting Plugs    | 1        |

| NO. | PICTURE | DESCRIPTION            | QUANTITY |
|-----|---------|------------------------|----------|
| 11  |         | M8X40 screws           | 9        |
| 12  |         | M8X50 screws           | 4        |
| 13  |         | M8X80 screws           | 6        |
| 14  |         | M8 anti-loosening nut  | 19       |
| 15  |         | Hexagonal wrench       | 1        |
| 16  |         | Expansion screws       | 4        |
| 17  |         | Straw basket pins      | 2        |
| 18  |         | Rail Mounts            | 6        |
| 19  | Omme    | Self tapping screws    | 4        |
| 20  |         | M10X50 screws          | 4        |
| 21  |         | M10 anti-loosening nut | 4        |


# TMG-FSH13A INSTALLATION INSTRUCTIONS STEP1



| No. | Part | Qty |
|-----|------|-----|
| 1   |      | 1   |
| 11  |      | 6   |
| 14  |      | 6   |

#### As shown in the picture


- 1. Drill through the board with an M8 drill bit into the round hole pointed out by the arrow.
- 2. Tighten the screws and nuts according to the arrow.



| No. | Part | Qty |
|-----|------|-----|
| 5   |      | 1   |
| 13  |      | 6   |
| 14  |      | 6   |
| 18  |      | 6   |

As shown in the picture


1. The rail mounting base, rail with M8 \* 80 screws and nuts according to the direction of the arrow to install the fastening



| No. | Part | Qty |
|-----|------|-----|
| 7   |      | 1   |
| 15  |      | 1   |

#### As shown in the picture


1. Insert the rail limiter into the rail and tighten it with a hex wrench.



| No. | Part | Qty |
|-----|------|-----|
| 2   |      | 1   |
| 11  |      | 3   |
| 14  |      | 3   |

#### As shown in the picture


1. Drill through the stable door in the direction of the arrow with an M8 drill bit and fasten with M8\*40 screws and nuts.



| No. | Part | Qty |
|-----|------|-----|
| 2   |      | 2   |
| 12  |      | 4   |
| 14  |      | 4   |

#### As shown in the picture


1. Tighten the barn wheel in the direction of the arrow with M8\*50 screws and nuts.



| No. | Part | Qty |
|-----|------|-----|
| 2   |      | 1   |

#### As shown in the picture


1. Push the installed stable door into the rail according to the direction of the arrow




| No. | Part  | Qty |
|-----|-------|-----|
| 8   |       | 2   |
| 19  | Dunne | 4   |

#### As shown in the picture

1. Fix the stable door stopper to the stable door with self-tapping wire according to the appropriate position, and adjust the distance of the stopper pulley to the appropriate position.







| No. | Part | Qty |
|-----|------|-----|
| 7   |      | 1   |
| 15  |      | 1   |

#### As shown in the picture

1. Insert the other side of the rail limiter into the rail and tighten it with a hexagonal wrench.






| No. | Part | Qty |
|-----|------|-----|
| 3   |      | 1   |
| 17  |      | 2   |

#### As shown in the picture


Place the hay basket on the stable door and secure it with a pin inserted in the direction of the arrow.



| No. | Part | Qty |
|-----|------|-----|
| 4   |      | 1   |
| 20  |      | 4   |
| 21  |      | 4   |

#### As shown in the picture


1. According to the direction indicated by the arrow, fasten the fine material groove with M10\*50 screws and nuts.



| No. | Part | Qty |
|-----|------|-----|
| 9   |      | 1   |

#### As shown in the picture

1. Insert the mounted stable front door into the base according to the direction of the arrow




| No. | Part | Qty |
|-----|------|-----|
| 10  |      | 1   |

#### As shown in the picture

1. Insert the connecting plug into the front door of the stable as indicated by the arrow.

### Installation complete



**Assembled**