

Custom Wavefold drapery instructions

Fabrication

1. Use the chart to determine your panel width, number of hooks and hook spacing.
2. Fold down a 1" hem at the top and pin the wavefold tape in place. For Renaissance brand tracks (Professional, Principal, Heavy Duty H, Silent Glide and Motiva; put the top of the tape at the top of the drapery. For all other rods, move the top of the tape down 3/16". This will make the top of the drapery flush with the bottom of the rod. Sew a row of stitching across the top and bottom of the wave fold tape.
3. To attach hooks to the wave fold tape, turn them upside down and insert from the bottom of the loop.
4. Put the first hook approximately 2" from each end. Space the remaining hooks evenly across the panel according to the chart. **Remember that you must have an even number of hooks.**



5. If using the Neat Pleat guide baton holder, add one additional hook 2 1/2" inside the first hook.



50% fullness



100% fullness

Wavefold Chart for 2 3/8" carrier spacing-All rods come with this carrier only. Fullness is adjusted with hook spacing.

Panel coverage is the length of your track if using one panel, half the length of your track if using two panels, etc.

Example: Using two panels on a 112" track; Each panel will need to cover at least 56". Find where 56" falls in the first column for panel coverage. Since 56" is more than 54", move down to the 59" row. Move across the row to your desired fullness.

For draperies with 100% (double) fullness, you will need two panels 123" wide with 26 hooks spaced 4 3/4" apart.

Your first and last hook will be approximately 119" apart in this example (25 spaces times 4 3/4"). This leaves about 2" before the first hook and 2" after the last hook for a total of 123". Always use an even number of hooks.

Fullness % / Hook spacing in inches								
Panel width in inches (includes 2" before the first hook and after the last hook)								
Panel coverage/in.	60%/3 3/4"	70% / 4"	80% / 4 1/4"	90% / 4 1/2"	100% / 4 3/4"	110% / 5"	120% / 5 1/4"	# hooks
11.5	23	24	25.5	26.5	28	29	30.5	6
16.5	30.5	32	34	35.5	37.5	39	41	8
21	38	40	42.5	44.5	47	49	51.5	10
25.5	45.5	48	51	53.5	56.5	59	62	12
30.5	53	56	59.5	62.5	66	69	72.5	14
35	60.5	64	68	71.5	75.5	79	83	16
40	68	72	76.5	80.5	85	89	93.5	18
44.5	75.5	80	85	89.5	94.5	99	104	20
49.5	83	88	93.5	98.5	104	109	114.5	22
54	90.5	96	102	107.5	113.5	119	125	24
59	98	104	110.5	116.5	123	129	135.5	26
63.5	105.5	112	119	125.5	132.5	139	146	28
68	113	120	127.5	134.5	142	149	156.5	30
73	120.5	128	136	143.5	151.5	159	167	32
77.5	128	136	144.5	152.5	161	169	177.5	34
82.5	135.5	144	153	161.5	170.5	179	188	36
87	143	152	161.5	170.5	180	189	198.5	38
92	150.5	160	170	179.5	189.5	199	209	40
96.5	158	168	178.5	188.5	199	209	219.5	42
101	165.5	176	187	197.5	208.5	219	230	44
106	173	184	195.5	206.5	218	229	240.5	46
110.5	180.5	192	204	215.5	227.5	239	251	48
115.5	188	200	212.5	224.5	237	249	261.5	50
120	195.5	208	221	233.5	246.5	259	272	52
125	203	216	229.5	242.5	256	269	282.5	54
129.5	210.5	224	238	251.5	265.5	279	293	56
134.5	218	232	246.5	260.5	275	289	303.5	58
139	225.5	240	255	269.5	284.5	299	314	60
143.5	233	248	263.5	278.5	294	309	324.5	62
148.5	240.5	256	272	287.5	303.5	319	335	64
153	248	264	280.5	296.5	313	329	345.5	66
158	255.5	272	289	305.5	322.5	339	356	68
162.5	263	280	297.5	314.5	332	349	366.5	70
167.5	270.5	288	306	323.5	341.5	359	377	72
172	278	296	314.5	332.5	351	369	387.5	74
177	285.5	304	323	341.5	360.5	379	398	76
181.5	293	312	331.5	350.5	370	389	408.5	78
186	300.5	320	340	359.5	379.5	399	419	80
191	308	328	348.5	368.5	389	409	429.5	82
195.5	315.5	336	357	377.5	398.5	419	440	84
200.5	323	344	365.5	386.5	408	429	450.5	86
205	330.5	352	374	395.5	417.5	439	461	88
210	338	360	382.5	404.5	427	449	471.5	90
214.5	345.5	368	391	413.5	436.5	459	482	92
219	353	376	399.5	422.5	446	469	492.5	94
224	360.5	384	408	431.5	455.5	479	503	96
228.5	368	392	416.5	440.5	465	489	513.5	98
233.5	375.5	400	425	449.5	474.5	499	524	100