

WAVESOUND2



User Guide

Contents

1. Introduction	. 2
2. Battery Precautions	. 3
3. Getting Started	. 4
4. Cable Connection	. 5
5. Bluetooth Connection	. 5
6. NFC Connection	. 6
7. Function Guidance	. 7
8. LED Display Status	. 7
9. Battery Charging	8
0. Product care	8

Please read the following safety warnings and precaution before using this device.

1

Specification

Paww WaveSound 2

Range:	65.6' (20m)		
Driver:	40mm Neodymium		
Frequency range:	20Hz-20KHz		
Battery:	3.7v, 800 mAH replaceable		
Functional Speics:	Bluetooth, Hands-free, ANC, NFC		
Size:	166x92x181mm		

1. Introduction ____

Congratulations on your purchase of Paww WaveSound 2; one of the most advanced headphones systems on the market. Paww WaveSound 2 has been engineered to provide you with years of enjoyment and comfort. Experience music without compromise. Experience Paww WaveSound 2.

2. Battery Precautions ____

The Paww WaveSound 2 can be powered by a built-in rechargeable lithiumion battery. Please charge the battery for at least 8 hours before first use.

- If the device has not been used for an extended period of time, the battery may be drained of power and require recharging.
- Rechargeable batteries should only to be charged under adult supervision.
- Only use the supplied micro-USB cable to recharge the battery. Improper charging may damage the battery and the device.
- Do not attempt to open the rechargeable battery or battery pack. There
 are no serviceable parts inside.
- Keep the battery out of reach of children. If swallowed, consult a physician immediately.
- Avoid storing the battery in extremely hot or cold environments. A device
 with a hot or cold battery may not work temporarily, even when the
 battery is fully charged.
- Do not dispose of the batteries in a fire as they may explode. Batteries may also explode if damaged. Please dispose of them according to local regulation. Do not dispose of batteries as household waste.

3. Getting Started







5. Bluetooth Connection

The Paww WaveSound 2 headphone system can be paired with most Bluetooth enabled devices with the range of 20 meters (65.6 feet)

1. Activate pairing mode on the Paww WaveSound 2 by turning the switch to "BT" mode. The LED will flash blue in color.

On your Bluetooth enabled device, navigate to the settings menu, and select the Bluetooth option.

- 3. Select "Search" or "Discover" devices.
- 4. Select "WAVESOUND 2".
- 5. If requested, type the password or PIN as 0000
- 6. Press the Enter key to complete setup.

After completing the steps above, a message on your Bluetooth enabled device will appear confirming that the pairing process was successful. In case the pairing in unsuccessful, please restart the Paww WaveSound 2 and try again. If the Bluetooth on your smart device remains open, when you restart the headphone, the Bluetooth will be connected automatically.

6. NFC Connection



NFC or (Near Field Communication), is a set of standard for wireless devices to establish radio communication between compatible devices by touching them together or bringing them into close proximity to each other.

Please activate the NFC function of your NFC enabled Bluetooth device and put the device close to the Paww WaveSound 2. Your device will ask you if you want to pair the two device, choose Yes or OK to complete the pairing process.

7. Functional Guide _____

Playing music

Button	Operation	Function
•	Long press	Volume up
•	Short press	Next song
0	Long press	Volume down
•	Short press	Previous song
Δ	Short press	Play/Pause, Answer/End a call.
Δ	Long press	Ready for pairing

8. LED Display Status _____

		LED Display	Light indication
Right LED Blue	Rluo	Flash	Power ON
	Dide	Stay Solid	Paired
	White		Active noise cancelling ON
Left LED	Red		Charging in process
Leit LED	OFF		Fully charged

9. Battery Charging

This Paww WaveSound 2 has a built-in rechargeable lithium-ion battery that can be charged by connecting the supplied cable to a USB port of your computer or into an AC adapter with USB port. When charging is completed, the red light will go off.

10. Product care

This device is designed to be light, compact and durable. As an electronic device it must be treated carefully. Putting unnecessary pressure on it or striking the device against other objects may cause damage. To avoid damage to your device, please:

- · Do not drop, crush, bend or apply excessive force to the device.
- Do not expose your device to moisture, extreme or prolonged heat, cold, humidity, or other adverse conditions. Avoid storing it in damp, humid or wet places, as it is not waterproof.
- Clean the unit with a soft cloth or damp chamois leather. Never use solvents.
- · The unit can only be opened by qualified personnel.
- This unit contains magnets. Keep magnetic field sensitive products such as credit cards and video screen away from this device to avoid damage or malfunction.