



WAVESOUND 3



FC CE USER GUIDE

Congratulations on your purchase of the Paww WaveSound 3! Please read the instructions and warnings carefully before use to ensure safe and satisfactory enjoyment of this product.

www.mypaww.com


Important safety information

- Always use the headphones at an appropriate volume. Prolonged exposure to loud sounds may damage your ears.
- Do not turn up the volume so high that you cannot hear sounds around you.
- Use caution or temporarily discontinue use in potentially hazardous situations.
- Do not use the headphones while riding a bicycle, or operating a motor vehicle. The use of headphones may create a traffic hazard and is illegal in many areas.
- Exposing these headphones to open fire can be dangerous, as they contain a lithium ion battery.
- Do not disassemble the headset, unless qualified to do so.
- Place out of reach of small children, as the packaging contains small parts.

WARNING

This equipment is not waterproof. To prevent a fire hazard, do not expose the headphones to water or fire sources.

Description of the Paww WaveSound 3



Specifications

- Bluetooth Solution: CSR
- Bluetooth version: V4.0
- Profiles Supported: A2DP, AVRCP, HFP, HSP
- Operating distance: 10m or 33ft
- Battery: 300mA
- Charging time: about 2 hours
- Charging current: 200mA
- Music playing time: approximately 16 hours (at 50% volume, and with noise cancelling off)
- ANC working time: approximately 8 hours
- Driver Unit: Ø40mm
- Sensitivity: 105dB/1mW(S.P.L at 1KHz)
- Frequency Range: 20Hz-20KHz
- Rated Power: 10mW

Charging the Battery

The Paww WaveSound 3's battery must be charged before use. The included micro-USB cable can be used to perform this operation.

Connect the micro-USB cable to the micro-USB port on the headphones, and the USB plug on the other end of the cable to a USB port on a computer, or a USB-compatible wall charger.

When the charging process begins, the LED indicator on the headphones will turn red. It takes about three hours to achieve a full charge; when the charging process is complete, the LED indicator will turn off. When the battery's charge is nearly depleted, a beeping sound will be heard in the headphones at one-minute intervals.

Note:

- Battery recharging time and usage time may vary depending on ambient temperature and frequency of use.
- Do not place metal objects near the headphones' charging contacts, as this could result in a short circuit, or overheating of the unit.

- Please do not attempt to change the rechargeable lithium ion battery
- Please do not dispose of used batteries/electronics with ordinary solid waste, as they contain toxic substances.
- Please turn off your headset after use to prolong battery life.

Pairing the headset with Bluetooth devices

1. With the headphone power OFF, keep the Bluetooth button depressed for three seconds or more to power on and enter the pairing mode. The pairing mode is confirmed by the LED indicator flashing blue and red.
2. If the pairing process is not completed within 5 minutes, the power will turn off automatically.
3. On your Bluetooth enabled device, navigate to the settings menu, select the Bluetooth option.
4. Select 'Search' or 'Discover' devices.
5. Select 'WAVESOUND 3'.
6. If requested, type the password or PIN as '0000'
7. Pairing is confirmed when the LED indicator flashes blue at three second intervals.

Noise Cancelling Function

To activate the noise cancelling functionality, slide the NC button to 'On'. The noise cancellation feature will work independently of the Bluetooth connection. This allows you to use the headphones with noise cancellation, even when using a wired connection.

Making calls with the headset

Functions	Status of headset	Operation
Redial last number	Standby mode	Short press bluetooth button twice quickly
Volume up	Conversation mode	Short press the "+" button

Volume down	Conversation mode	Short press the "-" button
Answering a call	Ringing	Short press bluetooth button
Rejecting a call	Ringing	Press and hold bluetooth button for one second, and release until you hear the indication sound

Note:

Not all phones support the functionality listed above. Please refer to the instruction manual of your phone for more information. Some functions and indication tones may vary with different phones

Playing Music

Controls when listening to music

(+) button

Press once or keep pressed to increase the volume

Forward button

Press once to return to the beginning of track or chapter

(-) button

Press once or keep pressed to decrease volume

Next button

Press once to skip to the next track or chapter.

Bluetooth button

Press once: play/pause

Note:

- When sound volume is set being adjusted, the headphones will beep once when the maximum or minimum volume is reached.

Disconnecting from a Bluetooth device

Press and hold the Bluetooth button for about five seconds to turn off the power.

Troubleshooting

Problem	Remedy
Power won't turn on	Recharge the wireless headphones
The batteries will not charge	Confirm that computer is ON, or wall charge is plugged in. Confirm that computer is not in power-saving mode. Confirm that the micro-USB cable is securely connected to both the Paww WaveSound 3 headphones and the power source.
Unable to pair using Bluetooth	Place the wireless headphones and Bluetooth device close by when pairing. Confirm that power is turned on for both the devices. Confirm that Bluetooth functionality is enabled on the device you are connecting to.
No sound when playing music	Confirm that power is turned on for both the headset and the Bluetooth device you're connected to. Confirm that sound volume controls on both wireless headphones and music playback device are set to appropriate levels.
Sound is distorted when playing music	Check that no other devices utilizing the 2.4GHz wavelength around you. This could lead to interruption in data transfer between the headset and the Bluetooth device.
Can't use the hands-free operation	Confirm that wireless headphones and bluetooth device are connected and using the HFP or HSP profiles. If connection to the Bluetooth device is in A2DP profile, then it might be necessary to change connection profiles (depending on the specifications of your Bluetooth device).
Communication distance is short, sound is garbled.	Check that you're not near any other devices that utilize the 2.4GHz wavelength. Examples of such devices include microwaves, wireless radios, etc.