


BEARGREASE SIZE CHART

To find your frame size, take the following measurements and refer to the size chart below.

- 1. What is your height?
- 2. Determine one of the following:
 - a. What is your inner leg length?
 - b. What is your existing saddle height?
- 3. To determine your frame size using inner leg length find your height across the top row and your inner leg length measurement in the column on the left-hand side of the chart. Locate the point where these values intersect to get your target frame size.
- 4. To determine your frame size using existing saddle height find your height across the top row and your saddle height in the column on the right-hand side of the chart. Locate the point where these values intersect to get your target frame size.



Notes about Sizing Results:

- 1. If your recommended frame size falls in the overlap between two sizes:
 - a. You can reliably fit either size frame (length and standover) and achieve your required saddle height with OE equipment (unless noted). Consider the follow to help choose:
 - Select the larger of the two sizes if you prefer a roomier fit and a more stable bike. You may want to consider a 10mm shorter stem if you feel too extended.
 - ii. Select the smaller of the two sizes if you want a bike with more nimble handling. You may want to consider a 10mm longer stem if you feel cramped.
- 2. If your measurements result in a coordinate that is outside the recommended size zones to the RIGHT AND ABOVE:
 - a. Your inner leg length measurement is shorter than average (double check this measurement).
 - b. You can likely ride the larger frame size indicated below your position on the chart, but may not have sufficient standover and will likely need a shorter seatpost than what is included with the bike.
 - c. You can likely ride the smaller frame size indicated to the left of your position on the chart, but you may need a longer stem and/or higher handlebar position to dial in the length of the bike.
 - d. Consult your local Salsa dealer, professional fitter, or Salsa customer support for further guidance.
- 3. If your measurements result in a coordinate that is outside of the recommended size zones to the LEFT AND BELOW:
 - a. Your inner leg length measurement is longer than average (double check this measurement).
 - b. You can likely ride the smaller frame size indicated above your position on the chart, but might need a longer seatpost to accommodate your higher saddle height.
 - c. You can likely ride the larger frame size indicated to the right of your position on the chart, but you may need a shorter stem and/or lower handlebar position to dial in the length of the bike.