

# ChargeUp Pro 10K

## 10,000 mAh Portable Powerbank

### Recharge your ChargeUp Pro

To recharge your ChargeUp Pro, connect it to a computer, car-charger or wall-charger via the Micro-USB input **(E)**, using the Micro-USB cable provided. When charging, the LCD display **(B)** will flash, indicating remaining charge.

### Charge your device

Using your device's USB charging cable (not included), connect your device to either the USB-A **(C)** or USB-C output **(D)**. Press the power button **(A)** once to start charging your device. Your device should indicate that it has begun to charge. The LCD display **(B)** will now indicate your ChargeUp Pro's remaining charge. Repeat steps above to charge a second device. When you are finished charging your device/s, detach them from your ChargeUp Pro. It will turn off automatically.

### LCD charge indicator

To check your ChargeUp Pro's remaining charge, press the power button **(A)** once. The LCD display **(B)** will show the remaining charge from 0 to 100.

- A** - Power button
- B** - LCD display
- C** - USB-A output
- D** - USB-C output
- E** - Micro-USB input

### Product specifications


Battery type: Lithium battery  
Micro-USB Input: DC 5V - 2.0A (MAX)  
USB-C Input: DC 5V - 3.0A (MAX)  
USB-C Output: DC 5V - 3.0A (MAX)  
USB-A Output: DC 5V - 3.0A (MAX), 9V - 2A, 12V - 1.5A (QC3.0)  
Total Output: 18W (MAX)  
Operating Temperature: 0°C - 40°C

### Caution

Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

### Warning

Do not store cable with both connectors plugged into powerbank as this may short circuit powerbank and stop it from working.



### Important safety instructions

Please read and follow these instructions carefully and retain for your records. Please read all warnings for your safety and optimal user experience.

1. Never leave a charging battery unattended.
2. Do not expose the ChargeUp to excess humidity or liquids. It should be stored in a cool, dry place when not in use.
3. Do not damage or puncture the casing of the ChargeUp. This may cause over-heating, fire or an explosion.
4. Do not expose the ChargeUp to sources of heat, including radiators, stoves, or fires. Do not expose to ambient temperatures above 40°C, such as in a car on hot day, or in direct sunlight. Failure to do so may cause over-heating, fire, or explosion.
5. Do not use in a strong electrostatic or electromagnetic environment, including near microwaves as this may shorten the device's life.
6. If ChargeUp emits an odour, excessive heat or becomes discoloured or distorted, please discontinue use immediately.
7. Refer all servicing to qualified service personnel, which is required if ChargeUp is damaged in any way, is exposed to liquid or does not operate normally. Please do not attempt to service or open the device. This may cause over-heating, fire or an explosion.
8. If the battery electrolyte makes contact with skin or eyes, rinse thoroughly with water immediately and consult a doctor. The electrolyte is flammable and reaction with air may cause the chemicals to ignite, resulting in fire.
9. At the end of the device's life, please dispose of this product at a battery recycling station. It is not suitable for domestic waste disposal.
10. If a new ChargeUp is not used for a period of three months or more, its battery capacity will be reduced, but will restore to normal capacity after 3-4 charge and discharge cycles.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to connect the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help.