



9500B-SRL Installation Instructions

Product Overview:

Increase safety by illuminating your Road Glide to distracted drivers by using our bright white Midnight Edition LED Running lights. The bright white running lights have a greater viewing angle allowing you to see the sides of the road, signs, and safety hazards. The Harley Davidson Road Glide compatible running lights make you more visible to other drivers!

Typical Installation

Required Tools

- 5/16th Inch Bit
- Masking Tape
- Electric Drill

Installation Warning

If you feel uncomfortable installing this product, we recommend having a professional complete the installation. Eagle Lights LLC is not liable for any damage to the product or vehicle due to an improper installation. If you have questions about the installation, please feel free to call us at 1-800-921-3162 or email us at Support@EagleLights.com.

Installation:

Below are steps for a typical installation on most Harley Davidson models. Steps may be different depending on the model. Please ensure you have read through the instructions and understand them clearly before attempting the installation.

▲	NOTICE!	▲
<ul style="list-style-type: none">• To prevent possible electrical shock, disconnect the negative battery terminal before installing this product.• Installation will require drilling two holes. Measure twice, drill once. Do not make holes too large.• Read and understand the instructions before completing the installation.		

1. Detach windshield by remove 4 screws. Place windshiled to the side.



2. Remove dash that is directly under the windshield by gently prying upward on the left and then the right side. Remove and place to the side.

3. Remove the speaker grills. Place your hand behind the speaker grill to pop it out of place.



3

4. Remove bolt by speaker. Do this on both sides.



5. Remove bottom screw on the fairing. Do this on both sides.



4

6. Unclip turn signal harness on each side.



7. Do not remove the fairing yet. Leave it on the bike so you can mock up the drill holes.
8. Apply masking tape



5

9. Align the turn signal in the vent.



10. Mark pilot holes on masking tape.



11. Drill with a 5/16 drill bit on both top and bottom.



6

12. Insert well nuts.



7

13. Remove fairing and place to the side.
14. Attach vent lights.



15. Connect lights to the turn signal harness.
16. Reinstall the fairing, dash, speaker covers, and windshield