

## Safety Information

### **Important! Please read below statements:**

1. Due to external factors all GPS devices can have inaccuracies of position; the position provided by this device is just a guide.
2. There may be delays caused by mobile phone operators in certain circumstances.
3. Frequency Precision does not accept any liability for any damage or injury, howsoever caused because of misuse of this equipment. It is the responsibility of the user to ensure that the equipment is operated in the manner for which it was intended and that it is the correct item of equipment for the required task. All systems can fail, and it is the responsibility of the user to carry out regular tests and to determine the suitability of this equipment for any application.
4. Remember, daily system tests should be carried out to ensure correct functioning of the unit. If the unit has been dropped or it is worn by a person involved in an accident the unit should be tested again before re-use.



**WARNING:** Failure to follow these safety instructions could result in fire, electric shock, injury, or damage to the device or other property. Read all the safety information below before using.

5. **This device is water resistant but should not be submerged in water. If the device has been submerged in water (e.g., in a washing machine) do not attempt to use or charge the device. The device should be returned to us for examination. If the device is dropped or receives an impact, the water-resistant features of the device may be damaged.**
6. **When charging the device, use only the supplied cable specifically designed for your device. Connecting the charger improperly, may cause serious damage to the device.**
7. **Using a damaged cable or charger or charging when it is wet/moisture is present, can cause fire, electric shock, injury, or damage to the device or other property. When you use the charging cable, make sure its USB connector is fully inserted into a compatible power adapter before you plug the adapter into a power outlet. It is important to keep the device, the charging cable, and the power adapter in a well-ventilated area when in use or charging.**
8. **If you suspect damage to the device or the battery, discontinue use, as it may cause overheating or injury. Signs of damage to the battery include the device emitting an unusual smell, feeling warm/hot, changing shape, or behaving abnormally.**
9. **Never leave your device charging unattended or overnight. Do not charge or store the device in direct sunlight.**