

Classic Greenhouse Manual



Tools Needed:

- Cordless Drill (12V or higher)
- #2 Square Drive Bit
- Hammer
- 6' Step Ladder
- Tape Measure
- Square utility knife
w/ blade & hook blade
- Speed Square
- 5/16" Wood Drill bit



Little Cottage Co.®
PO Box 455
Berlin, OH 44610
330-893-4212
www.cottagekits.com

© 2011 Little Cottage Co.

Classic Greenhouse Manual



1



Thank You for purchasing from Little Cottage Co.!!
Begin your kit by locating the 4x4 pressure treated runners. Place them roughly 6' apart.

2



Next locate 2x4's for floor.

3



Make sure joist and rim are flush as shown and secure with 2 1/2" screws.

4



Next measure 13" from outside to 4x4 runner.

5



Use square to place 4x4 as shown.

6



Make sure 2x4 and 4x4's are flush. Secure with 2 1/2" screws on angle as shown.

Classic Greenhouse Manual



7



Once 2x4's are in place, verify that flooring structure is square by measuring from corner to corner as shown.

8



Next measure 16" On Center, and secure 2x4's into 4x4 by toe nailing a 2 1/2" screw on both sides.

9



Set sheeting in place using angles to ensure sheeting is flush on both sides. Secure in place by driving 1 1/4" screws through the sheeting and into the 2x4's every 8".

10



Continue to set remaining sheeting until the entire floor is in place.

11



Next locate the walls.

12



Locate the first wall panel and set in place.

Classic Greenhouse Manual



13



Make sure stud is flush with edge of floor structure using an angle. Apply pressure from outside and secure with 2 1/2" screws.

14



Secure at the opposite end in a similar manner as well as at every stud in between.

15



Set the next panel in place.

16




Apply pressure on the outside as before and secure with 2 1/2" screw.

17



Next make sure walls are flush on inside and secure with 2 1/2" screw.

18



Use 1 1/4" screws to secure wall as shown.

Classic Greenhouse Manual



19



Set the next set of walls in place by letters.

20



Continue with walls per diagram as shown.

21



Make sure the walls are flush on the inside and secure with 2 1/2" screws as shown.

22



Next install end wall.

23



Apply pressure on outside while fastening with 2 1/2" screw from inside as shown.

24



Apply pressure on all walls as shown before securing with 2 1/2" screws.

Classic Greenhouse Manual



25



Next apply pressure on corners as shown.

26



Secure with 2 1/2" Screws on an angle.

27



Remove 2x4 plate underneath door.

28



Next install door panel.

29



Apply pressure on outside and secure with 2 1/2" screw.

30



Secure corner with 2 1/2" screw.

Classic Greenhouse Manual



31




Make sure you have 34" between door opening.

32



secure wall with 2 1/2" screws.

33



Secure 1 1/4" screws every 8" on bottom all around the outside.

34



Secure 1 1/4" screws every 8" on all corners.

35



Locate 2x6 top plates with 3/4" trim as shown.

36



Top plates are marked for trusses as shown.

Classic Greenhouse Manual



37



Wall is marked where Top plate starts.

38



Next install top plate, make sure 2x6 is at the pencil mark as shown on last picture.

39



Fasten with 2 1/2" screws every 16" o.c

40



Make sure the Top plate is flush on the inside as well as shown, before fastening.

41



Top Plates are complete.

42



Next locate gable wall and use it for truss assemble as shown.

Classic Greenhouse Manual



43



Lay rafters on top of gable so all trusses will be the same. Place Truss gussets as shown and secure with 1 1/4" screws.

44



Flip truss around as shown.

45



Repeat with gusset as shown. Truss gets a gusset on each side.

46



Next install gables.

47



Secure with 2 1/2" screws once gable is in place.

48



Make sure 2x4's are flush and secure with 2 1/2" screw as shown.

Classic Greenhouse Manual



49



Gables are completed.

50



Next set Trusses.

51



When securing truss use (3) 2 1/2" screws as shown (1) on top and (1) on each side of the truss.

52



Trusses are completed.

53



Next locate 2x3's for Purlins.

54



Purlins will be installed on top of trusses for Sunsky to set on.

Classic Greenhouse Manual



55



Continue with purlins.

56



Purlins are marked so customer knows where to place them. Bottom row purlins are cut on an angle as shown.

57



Secure with 2 1/2" screws.

58



Locate 2x2 Bird Blocks.

59



Install 2x2 Bird Block on top of gable as shown, and secure with (2) 2 1/2" screws.

60



Repeat on other end.



61



Next install second row of purlins as shown.

62



Install 2x2 bird block on gables after every row of purlins.

63



Continue with purlins.

64



Install last bird block as shown.

65



Install last row of purlins.

66



Secure with 2 1/2" screws.

Classic Greenhouse Manual



67



Purlins are completed.

68



Locate 2x4 rakes with trim.

69



Locate rake blocks.

70



Install rake blocks as shown.

71



Secure with 2 1/2" screw as shown.

72



Secure with second screw from bottom up.

Classic Greenhouse Manual



73



Next locate the 7/16 siding for soffit.

74



Install 7/16" siding for soffit as shown. Install longer piece first and then shorter one on the other side.

75



Secure with 1 1/4" screws.

76



Install shorter piece.

77



Next install rakes with trim on the outside as shown.

78



Make sure it is flush on the top of the purlins and secure with 2 1/2" screws.

Classic Greenhouse Manual



79



Continue with 2 1/2" screw going from top of purlin into the rake on an angle.

80



Install rake on left side and repeat from first one.

81



Make sure peaks lineup. Secure with 2 1/2" screws.

82



Locate corner trim.

83



Install corner trim as shown.

84



Secure with 1 1/4" screws as needed on all 4 corners.



85



Locate window trim.

86



Install window trim.

87



Secure with 1 1/4" trim as needed.

88



Next install 3" siding strip below door opening and secure with 1 1/4" screws.

89



Locate Door.

90



Next install top door first and make sure you have a 1/4" space on top as shown. Secure with 2 1/2" Black Headed Screws.

Classic Greenhouse Manual



91



Continue with door.

92



Next install bottom half of door.

93



Secure with 2 1/2" black headed screws.

94



Next secure bottom hinge with 2 1/2" black headed screws.

95



Locate door latch and barrel bolts.

96



Next install door latch as shown.



97



Make sure you use angle square as shown, so latch is flush with trim.

98



Secure with 1 1/4" black headed screws.

99



Install inside part and secure with 1 1/4" black head screw.

100



Next install latch closer onto trim as shown.

101



Secure with 1 1/4" black head screws.

102



Next install barrel bolt on inside top door and secure with 1 1/4" screw.



103



Push barrel bolt down and tap on with hammer to locate where to drill 5/16" hole.

104



Next drill 5/16" hole.

105




Locate hook eye.

106



Open top door to locate where to install hook and eye.

107



Drill 1/8" hole.

108



Install eye where hole was drilled.



109



This is what it should look like when completed.

110



Next locate interior shelves.

111



Install first section. Make sure top is flush with window sill.

112



Secure on bottom side with 2 1/2" screw going into 2x4 wall stud.

113



It should measure around 31" from floor to bottom of shelf.

114



Next secure with 2 1/2" screws as needed.

115



Next install second part.

116



Secure the 2 together with 2 1/2" screw.

117



Make sure all shelves are flush on top with window sills.

118



After both sides are installed, install center shelf and secure with 2 1/2" screws.



Secure with 1 1/4" screws, where needed on top.



Next install 2x2 braces.



121



Secure with 2 1/2" screw as shown on top.

122



Next secure bottom as shown with 2 1/2" screw.

123



This is what it looks like when done.

124



Locate 2 pipes for flower hangers.

125



Measure 12" from top plate to where pipe should be fastened.

126



Use 1 1/4" screws to secure pipe in place.



127



Install C-clamp on every truss.

128



Next locate upside down rubber closures.

129



Install rubber closures on bottom edge as shown.

130



Continue with rubber enclosures to the end.

131



Next install skylights.

132



Hang 1" over bottom, as shown.

133



Continue with roof. 1" overhang

134



Secure with 1" screw on every purlin and beside every rib.

135



Continue with roof.

136



Continue installing.

137



Make sure bottom over hangs 1"

138



Next install last piece as shown.

Classic Greenhouse Manual



139



Continue with roof as shown.

140



Locate metal rake covers.

141



Install rake cover with wider side on top.

142



Keep bottom flush with sky light as shown.

143



Secure with 1" white screw.

144



Insert screws so they line up with purlins as shown.



145



Continue with rake covers.

146



This is what it looks like when rake covers are done.

147



Locate ridge enclosures.

148



Locate ridge cap.

149



Next install ridge enclosures 2 1/2" from peak.

150



Continue installing enclosures.



151



Next install ridge cap over hang cap 1”.

152



Secure ridge cap with 2” white screw beside every rib.

153



Insert screw and make sure you don't take it all the way in. Make sure it lines up with sky light ribs.

154



Continue with ridge cap.

155



You may need to use extension ladder and have 1 guy at bottom to keep the ladder from kicking out.

156



Next install second piece as shown.



157



Continue with inserting 2" screws.

158



Once screws are in your building is complete!