

DIGITAL GAUGE & FAN KIT INSTALLATION GUIDE



TEMP SENSOR INSTALLATION GUIDE



Carefully insert the temperature probe into fins of radiator.

Make sure that the probe is lined up parallel to the fins to avoid damage. If it is too difficult to press in, use a small wood or plastic block against the back side of the sensor while guiding the sensor straight into the radiator.

(See photo to the left)

TIP: To Compensate for the influence of ambient air passing across the sensor, apply thermal grease (included in kit) into the gap between the fins of the radiator where the sensor will be installed. It is important to place the grease only in the gap. Grease on the surface of the radiator will attract dirt and reduce function.

