VAPESTIX™
By vapestix.com.au

EVOD KIT
1100 mAh

Filling with E-liquid

Step 1
Unscrew the tank from the battery.

Step 2
Make sure the tank is upside down then unscrew the tank base.

Step 3
Fill the tank with your e-liquid, ensuring that you avoid filling the hole in the centre of the tank, which is used for airflow. Do not over fill the tank so e-liquid spills into the centre hole.

Step 4
Reattach the tank base to the tank then reattach the battery.

1

General Use

Turning on and off

Press the button five times quickly to turn on or off; if done correctly the button will then flash three times.

If the device is off, the button will not glow when you press the button.

Inhaling

With the device turned on and filled with e-liquid, press and hold the button while inhaling from the mouthpiece.

While you are holding the button you will hear a sizzling sound and the button will glow.

If this does not happen, try turning it on or recharging.

2

WARNING:

This product is not to be used by people under 18 years or those that are pregnant or breatfeeding.

Please check with you doctor if you have any medical conditions or are at risk of conditions that may prevent you from using this product such as heart disease, high blood pressure, diabetes, etc.

This device is only to be used with high quality e-liquid. Please check the label of the e-liquid that you choose to use for directions, ingredients or any warnings.

Specifications

Tank Capacity: 1.8ml
Battery Capacity: 1100mAh

Voltage: DC 3.3 - 4.2v
Clearomizer Resistance: 1.8-2.8Ω
Charging: DC 4.2V/420mAh
Auto cut off: $15s\pm1s$ (Cut off automatically in 15s).

Made in China

3

Components

Tank and Battery   Tank (Disassembled)   USB Charging Cable

Recharging the Battery

If the light flashes when inhaling or does not turn on you need to recharge the battery

1. Unscrew the battery from the tank
2. Screw the battery into the USB Charging cable.
3. Plug the USB cable to a power adaptor or USB port

Charging (Red)   Fully Charged (Green)

4

Changing the coil

The coil needs to be regularly changed. You will notice that it needs to be changed if there is a burnt taste or the taste begins to change to an unpleasant flavour. Depending on how often the device is used, this may need to be changed every 1-4 weeks.

Step 1
Unscrew the tank from the battery.

Step 2
Make sure the tank is upside down then unscrew the tank base.

Step 3
Unscrew and discard the old coil from the tank base.

Then screw the new coil onto the tank base.

Step 4
Reattach the tank base to the tank then reattach the battery.

5

Safety Information

1. This is a sensitive electronic product, keep it from colliding with other items or from drops, throws or mishandling. Do not overcharge the battery or use a charger higher than DC 5.5V/500mAh. Keep the device away from excessive heat.

Any of these actions can damage the battery and could cause the battery to leak, burn or explode. If you suspect that the battery has been damaged we recommend that you dispose of the product imminently.

2. The device and its components must be kept out of reach of children and pets. The small parts are a choking hazard and all components must be disposed of properly.

3. Do not attempt to repair the device, including the battery, by yourself as damage or personal injury may occur.

4. The device is not waterproof, keep it dry at all times.

5. When not in use, turn off the battery. If not in use for an extended period of time, disconnect the atomiser/tank from the battery.

6

Common Issues/FAQ

Q: When inhaling, the LED light turns on but there is no vapour.
A: Make sure:
  1. The coil is screwed in correctly to the tank base
  2. The tank is well connected to the battery
  3. The tank is not empty of e-liquid

Q: When inhaling, there is a burnt taste
A: Change the coil. Also, if you have operated the device without e-liquid in the tank the coil will be burnt and need to be replaced early.

Q: Cleaning the tank or the tank is leaking
A: Often leaking is caused by e-liquid in the seal on the tank so clean the tank and seal by following these steps:

Step 1   Disassemble the tank into three parts.
Step 2   Discard the used coil. You should be left with the tank and tank base.
Step 3   Soak or wash the tank and tank base in warm soapy water, then rinse with clean water.
Step 4   Soak or wash the tank and base with isopropyl alcohol, then rinse with water; ensuring there is no residue.
Step 5   Let it air dry, then install the new coil and reassemble.

7