


Use this tool to make sure your BMFs are properly adjusted for your Telemark boots with a proper amount of spring "pre-load."

1. Place your boot fully in the binding with the Heel Lock engaged
2. Align this tool with the back end of the tube, as shown below
3. Check that the back end of the REAR CASE lines up somewhere in the ACCEPTABLE zone like shown below



GOOD TO GO SHRED!

