ColorFit Caliber Buzz

Please refer to this manual before using the product

WATCH FEATURES

- Activity
- Sleep
- SpO2
- Heart rate
- Stress
- Breathe
- Cycle tracker
- Alarm
- Stopwatch
- World Clock
- Timer
- Workouts
- Sport record
- Weather
- Music
- Breathe
- Reminders
- Flashlight
- Watch faces
- Settings

PACKAGE CONTAINS

ColorFit Caliber Buzz Smartwatch x 1

Charging cable x 1

CHARGING THE COLORFIT CALIBER BUZZ SMART WATCH

Before using your ColorFit Caliber Buzz for the first time, charge the battery to its full capacity. Use the charging cable provided with the watch to charge. On a full charge, ColorFit Caliber Buzz can last up to 7 days.
Note: The battery life and time to fully charge your device may vary as per usage and other factors.

To charge ColorFit Caliber Buzz

- Plug the USB cable into a power adaptor. Plug the power adaptor into an electrical socket (Power adaptor not included).
- Place the magnetic charger on the magnetic charging points of the watch.
- While your watch is charging, the screen will show its progress.
- Once the battery is fully charged, remove the charger.

POWER ON

Press and hold the side button for a few seconds to turn on the watch.

POWER OFF

Press and hold the side button for a few seconds, select 'Shut down' and confirm to power off.

WAKING UP THE WATCH

To preserve battery, the watch screen turns off when not in use. To turn the screen back on, you can wake up the watch by:

- Pressing the side button
- Turning on the wrist sense

POWER ON

POWER OFF

WATCH NAVIGATION

The ColorFit Caliber Buzz smartwatch has a 1.69" display touch screen. Navigate the watch by tapping on the screen, swiping side to side, up and down and pressing the side button.

HOME SCREEN NAVIGATION

The home screen is the watch face.
From the home screen:

- Swipe left or right to access widgets and shortcuts.
- Swipe up to go to quick settings menu.
- Swipe down to check your message notifications.

BUTTON NAVIGATION

- Press the side button to turn on the watch display.
- Press the side button again to go to the main menu.

SETUP

Before pairing, make sure that your smartphone and smartwatch are next to each other.
The app will ask for personal information such as height, weight and sex to calculate your stride length, distance covered, calorie burn rate.

- Turn on Bluetooth and the location on your mobile device.
- In your smartphone, download the NoiseFit app from the Play store or the App store and install it.
- Create an account or login using an existing account.

Note: Ensure that your smartphone is running on Android 4.4 or iOS 11+ and is connected to mobile data or a Wi-Fi network.

PAIR THE WATCH

- Open the NoiseFit app and allow the Bluetooth and GPS positioning to be turned on.
- Feed in your personal information and health goals in the app.
- Go to 'Pair Device' page in the app, select the watch name and MAC address and link the watch
  Or you can follow these steps:
- Turn on the watch.
- Scan the QR code from the NoiseFit app on your phone.
- Select Pair with device and wait for it to pair.

WATCH FACE

You can switch between different watch faces in the watch, choose and download cloud-based, animated watch faces or create your own watch faces in the NoiseFit app.

CHANGING THE WATCH FACE

Give your screen a personalised style by changing or customising the watch face from the NoiseFit app or the watch.

ON THE WATCH

Touch and hold the home screen. Swipe and choose from the watch faces.

IN THE APP

Go to watch faces, select the watch face of your choice and tap save to change the watch face.

SETTINGS

- Brightness
  - Set the watch brightness.
- Vibration
  - Set the vibration level as per your preference.
- Wrist awake
  - Turn on the wrist awake and set the auto screen off as per your preference.
- DND
  - You can choose to turn on the DND.
- Menu View
  - You can choose the way you want to see the watch features as per your preference.
- QR Code
  - Scan the QR code to connect with the app.
- Device Info
  - You will find all the information related to the watch name, including device name, Bluetooth name and version.

- Reboot
  - Go to reboot to restart your watch.
- Power of
  - Go to power of to turn of your watch
- Reset
  - You can choose to reset. Do note, if you choose to reset, all your data and settings will be erased.

Please note that some of the features might change after the OTA upgrade.

Features might change after OTA upgrade

ACTIVITY

You can check your daily activity progress in terms of the calories burned, steps taken, distance covered and active time.

HEART RATE

ColorFit Caliber Buzz supports 24/7 heart rate tracking. You can select the measurement frequency in the app settings. To measure your heart rate in real-time, go to the heart rate monitor. You can view the all-day data on the watch and app.

SPO2

ColorFit Caliber Buzz supports the viewing of highest and lowest blood oxygen level of the day. To measure your blood oxygen level in real time, go to the Blood Oxygen monitor and let it measure.
Note: Make sure your arms and wrists are still, and there is no space between your watch and the wrist

SLEEP

You can view your most recent sleep record and sleep quality in various sleep stages in the NoiseFit app. The feature will measure the device records of the user's sleep cycle, sleep stages (light and deep sleep), wake time and REM

STOPWATCH

A stopwatch can be set on the watch. You can also set lap times in the stopwatch.

STRESS

ColorFit Caliber Buzz supports 24-hour stress level measurement and viewing of all-day measurement data. To measure the stress levels real-time, go to the Stress feature and wait for it to measure.
Note: Make sure your arms and wrists are still and there is no space between your watch and the wrist.

BREATHE

The Breathe feature helps you adjust your breathing rhythm as per your convenience. You can choose from 3 speeds (fast, moderate and slow) to adjust your breathing duration. After the session, you can also see the change in the beats per minute.
Go to the Breathe feature, choose the time duration and speed and tap on start to enter the cycles of exhalation and inhalation.

NOISE BUZZ

ColorFit Caliber Buzz supports Bluetooth calls. You can dial, answer, silent and reject calls from the smartwatch as long as the watch's Bluetooth is connected with the smartphone and is within Bluetooth range. Go to Noise Buzz, connect your phone's Bluetooth with the ColorFit Caliber Buzz's Bluetooth to use the calling feature.

CONTACTS

You can choose to sync 10 contacts from your phone into the NoiseFit app which will be reflected on your watch. Choose from the list of saved contacts in your smartwatch and call.

CALL HISTORY

Choose from the call logs to call any of the previously contacted numbers.

FLASHLIGHT

You can use this feature to turn on the screen brightness and see your surroundings better. Go to the Flashlight. Tap to turn on.

ALARM

You can add, delete, and enable/disable alarms on the watch. You can set alarms in the NoiseFit app and they will sync with the watch. You can also label alarms to identify them.

TIMER

You can set a timer with a pre-set duration on the watch or set your own time and the timer will remind you when the time is up

DEVICE INFORMATION AND TIPS

DEVICE INFORMATION

The ColorFit Caliber Buzz smartwatch contains the following:

- 1.69" LCD Display Touch Screen
- Blood oxygen monitor
- Stress monitor
- IP68 waterproof
- 100 sports modes
- 22mm quick charge pins

The ColorFit Caliber Buzz smartwatch stores your activity data for up to 7 days in between the time you sync your watch to the NoiseFit app. Activity data includes your steps, distance, calories, active minutes, heart rate, sleep duration and workout data. We recommend syncing the watch to the app daily.

TIPS

How do I update my ColorFit Caliber Buzz?

You can update your ColorFit Caliber Buzz via the NoiseFit app. Go to My Profile and select Check forupdates.

How do I find my watch's current firmware version?

You can find the watch's current firmware on the watch. Go to Settings on the NoiseFit app. Select Device information, choose Check for updates and update if any update is available.

How do I save battery?

Follow these simple steps to save ColorFit Caliber Buzz battery.

- Minimise the screen brightness
- Limit the notification you receive from the NoiseFit app.

How does the watch estimate how many calories have been burned?

ColorFit Caliber Buzz estimates how many your blood oxygen level based on the physical data you entered when you set up your account.

How do I change my activity goals?

You can do it through the NoiseFit app. Go to My Profile. Go to Setup and select My Objectives. Change your goals and confirm.

How do I log my weight?

You can log in your weight the first time you setup your NoiseFit app. However, you can update the weight later via NoiseFit app. Go to My Profile, select Personal Information and change or update your weight. You can update birthday, height, country and e-mail ID as well.

DISPOSAL AND RECYCLING INFORMATION

Electrical and electronic devices may not be disposed of with domestic waste. Consumers are obliged by law to return the electrical and electronic device at the end of their service life to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. By recycling, reusing the materials or other forms of utilising old devices, you are making an important contribution to protecting our environment.

REGULATORY INFORMATION

USA: Federal Communications Commission (FCC) Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

This device may cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this 76 equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment of and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit dif erent from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The ColorFit Caliber watch is not a toy. The watch contains small components that could be a choking hazard and are not intended for use by small children or pets. Unless otherwise specified, devices and services are not a medical device and are not intended to diagnose, treat, cure or prevent any disease. We develop products and services to track daily activity and wellness information as accurately as possible. The accuracy of devices is not intended to be equivalent to medical devices or scientific measurement devices. In some cases, prolonged use of products may cause skin irritation. Prolonged contact may contribute to skin irritation or allergies in some users. To reduce the possibility of irritation, keep the watch and watch band clean and dry. Don't wear it too tight and give your wrist a rest by removing the watch after an extended period of wear. If you feel soreness, tingling, numbness, burning or stif ness in your hands or wrists while or after wearing the watch, please immediately discontinue use.

MAINTENANCE INSTRUCTIONS:

- Keep the device dry and clean regularly and especially after prolonged use as moisture and dirt can build up underneath the band and can cause skin irritation.
- Do not wear the device too tight but make sure that the bottom sensor is lightly in contact with your skin and there is a gap of about one finger's width between the wrist strap and your wrist.
- Do not use household cleaners to clean the device. Use soap-free cleaners instead.
- For stains that are dif icult to remove, it is recommended to scrub with alcohol.
- The device is not suitable for diving, swimming in the sea or sauna; it is suitable for swimming pool, shower (cold water) and swimming in fresh waves.
- Keep it away direct sunlight, high temperatures or humid conditions as it may damage the band over time.
- To prevent device damage, accessory damage and device failure, always protect the device against strong impact or shock.

SAFETY INSTRUCTIONS

- Do not disassemble the battery on your own.
- Do not expose ColorFit Pulse Buzz to extremely high or low temperatures. The excessive temperature during charging could cause heat, smoke, fire or deformation of the battery or even explosion.
- Charge the battery in a cool, ventilated room.
- Do not open, crush, bend, deform, puncture or shred secondary cells or batteries. In the event of a battery break or leak, prevent battery liquid contact with skin or eyes. If this happens, immediately flush the areas with water (DO NOT RUB THE EYES) or seek medical help.
- Do not short-circuit. Short-circuiting may damage the battery. Short-circuiting can occur when a metallic object, such as coins, causes the direct connection of positive and negative terminals of the battery.

- Keep the batteries out of children's reach and in a safe place to prevent danger.
- Do not place the batteries in the water.
- Do not use your product in a sauna or steam room.
- Do not dispose of batteries in the fire as that may cause an explosion. Dispose of used batteries in accordance with your local regulations. Do not dispose it as household waste.
- Use only the charging cable supplied to charge the battery. Do not charge for more than 24 hours.
- Do not attempt to repair or maintain the watch yourself, service and maintenance should be performed by authorized technicians only. Any device failure should be referred to our after sales service personnel.

CUSTOMER SUPPORT

If you experience any problem with the watch, it may be fixed by restarting your watch. For any assistance, please reach out to us at support.gonoise.in