



Korber Models

Scale Model Railroad Structures

165 E Main Street
Atlanta, IN 46031 USA
765-292-2044
www.korbermodels.com

Model TT2124 O Scale Locomotive Maintenance Facility Instructions

Compiled by: Tanya Burdick

Introduction













Congratulations, you have purchased the Korber Models #TT2124 Loco. Maintenance Facility. This structure represents thousands of buildings that could be seen along the tracks all across the nation. You can follow the simple, step by step instructions outlined in this document to easily assemble this great looking addition to your layout.

Before you start you may want to read through the instructions to get a feel for the things you will be doing, and the basic order in which they will be done. You are on your way to adding a great piece to your layout, so let's get started!



Parts list & Templates – (What's in the box)

Take a few minutes to locate all the parts in the box to make sure you have all the pieces you will need and that the quantities are right. If you are missing anything, please contact us so we can get you any of the missing items.

Qty	Description	Qty	Description
2	TT360 - 8" - (32 scale ft) Door Wall 	10	TT260 - 8" - (32 scale ft) Wall with window opening 
30	TT460 - 8" - (32scale ft) Blank Wall 	1	TT350 - 5" - (20 scale ft) Wall with Door opening 
10	Injection Molded 18 pane window 	3	Roof material 13" x 12.50" plus piece for seems 
1	Sheet of clear plastic "Window Glass"	8	14.75" - 1/4" x 1/4" wall brace material 
2	TT271 - 12 1/2" Window Wall (6pane) ,windows  	3	Injection Molded Entry Door 
2	TT470—12 1/2 Blank Wall 		2 Air conditioners, 8 round and 8 flat vents 

Materials needed – (What else might I need that is not included)

The Korber TT2124 Locomotive Maintenance Facility, like any kit, requires a few additional items to complete the construction. We have included a list here, including some color and brand suggestions based on our experience; however you may use any product that fits the function. Please also note that some items are listed as options such that they either make assembly simpler, or are needed only for optional steps

- Flat paint, choice of colors, for doors, windows, trim
- Light grey or cement color paint for walls
- RustOleum camouflage flat spray paints work well for painting the structure, window frames, and doors
- Paper towels or soft cloth rags
- Cyanoacrylate (CA) glue. Also known as Super Glue, Gorilla™ super glue works well
- CA glue accelerator (optional) (turns any CA glue into quick set glue (optional)
- Medium grit sandpaper or emery board
- Testor's Dull-cote™ (optional)
- Small clamps (optional)
- Flat black or grimy black spray paint (optional)

1 - Parts preparation & painting



Look over all the molded parts and remove any flashing that might be left on them. Flashing is the thin pieces of the molding material that may be left in widow openings and along edges in the molded parts. This can quickly be removed with a razor type knife, a small file, or an emery board.

The parts in the kit can be assembled in the color they come in or optionally you can paint them to the final colors you select, it is much easier to do this step before you completely assemble them. The windows and doors come colored in gray, however you may want to apply a light coat of flat paint in the color of your choice, RustOleum Camouflage spray paints give a great look. Paint in a well ventilated area (outside is good).



2 - Assembly of Walls

In this step we will assemble the four main wall sections of the structure prior to final assembly of the building. The assembly of the walls of the structure is based on gluing together several modular sections to make a continuous front wall. Below is a front view drawing of the relationship of the modular wall sections use to make the first wall.

- Some sanding may be necessary. Rough up edges only where you need to glue
- Glue two sections together aligning them on a flat surface face up and let dry
- Repeat the last step but using the remaining modular wall sections to create a continuous wall
- Optionally use clamps as necessary to hold pieces together
- Optionally you may want to use a brace across the back of several modules for added strength, cut the brace material as needed to fit
- Repeat the above steps for the next wall using the diagram below and the next page as a guide



All the wall sections come colored in a cement gray, however many modelers find a light coat of flat cement color or RustOleum Camouflage Khaki spray paint gives not only a great look, but also makes it easier to add weathering to the walls later on. In a well ventilated area (outside is good) apply a coat to the wall sections. Let the paint dry before moving to the next step




3 - Assemble & Install windows & doors

The windows & doors are made from injection molded plastic and will have a clear plastic sheet stock applied over the opening from the inside of the model to form a finished window.

- Carefully remove any flashing from the window & door frames
- If the window & door frames have not been painted, and if you would like to do so, paint them now and let them dry before moving to the next step
- Place the walls to which you want to add windows or door detailed (outside) side down on a flat surface
- The windows & doors are designed to insert in the opening from the back, or inside of the building
- Apply a small amount of glue around the edge of the frame and insert in the openings on the wall pieces
- Let the glued windows & doors dry before moving the wall sections to a vertical position to avoid glue running or the windows falling out
- Prepare to cut and glue small pieces of window material over the back of each window. Consider the following two window detailing option for the windows:
- If you want the window panes to have a hazed affect, lightly sand the window material until you've achieved desired haze affect prior to cutting into small window pieces
- You may also detail the windows with shades by covering the top portion of the window material with masking tape
- Cut window materials to fit over the back of each window & door – glue in place

4 - Assembly of Main Structure

The assembly of the main structure is based on making a simple rectangle shaped structure when viewed from the top. To the right is a top view drawing of the relationship of the wall sections.



Placement of walls

- Some sanding may be necessary. Rough up edges only where you need to glue
- Take sidewall one and the front wall (side wall three) and line them up to make a right angle. The use of a small square is helpful. The front wall should overlay the edge of the side wall . Dry fit the walls to ensure a smooth seam is made. You will note the walls have small tabs in the back of the wall to assist in alignment, you may need to trim flashing material from the alignment tabs on the back. Glue the two wall sections together.
- Repeat the last step but using the remaining side walls to make a rectangle.
- Optionally use clamps as necessary to hold pieces together.

5 - Install roof

The #TT2124 Locomotive Maintenance Facility has a single level rectangular flat roof made from a black material. The intent is to glue this piece to the molded cleats which are about 1/4" below the top of the wall sections of the building.

- The black roof material parts measuring 13" x 12.50" are designed fit together inside the four walls and rest on the molded cleats in the side walls. Use the smaller narrower roof pieces to add strength from underneath.
- Trim roofing material to fit snugly against the walls.
- Make sure there is no support roofing along edges, so roof will sit flat on molded cleats. You can glue in this place. You may want to paint the upper inside section of the walls black to match the roof material. As an option, you can use fine gravel to glue to roof for more realistic feel.

6 - Build Rooftop Air Conditioning Unit

The roof top Air Conditioner unit consists of six parts, four walls, a top and a bottom, all of which may be attached to the same sprue.

- Trim flash or sprue from the pieces to create the six parts, two end walls, two side walls, a top (larger) and a bottom.
- The parts come molded in a silver color, and do not need to be painted.
- Glue together the four sides to make a rectangle with two ends (shorter) opposite each other and two sides (longer) opposite each other. Use a small square if needed to make a right angle joint.
- Once the side sections are dry, glue the bottom section to the underside of the assembly between the legs.
- Once the bottom sections is dry, glue the roof section to the top to enclose the structure
- The final product should look like the photo to the right.
- Repeat the above steps for the second unit
- Place on the roof and glue in place



7 - Final Detailing – Weathering

Your Korber Models #TT2124 Locomotive Maintenance Facility is now assembled and ready for placement on the layout. You may wish to provide some additional weathering before you install it as a building next to the tracks would be a heavily used structure with a layer of soot, and would rarely look brand new.

To add a weathered look, spray the entire model with flat black from a distance. This will give a sooty look to the building. Once done you can spray the completed structure with Dullcote to remove any gloss or shine.

If you choose not to detail the inside of your structure, or light it, an effective and quick way to make a good looking background building is to cover the widows with black construction paper from the inside. This creates a dark building look that is more desirable than the view in to an otherwise empty shell of a building.