

PASSENGER SIDE

INCLUDED IN KIT

- x2 Headlights
- x2 Headlight LED Drivers
- x2 Vehicle Relay Harness (if applicable)
- Angel eye / Halo / Devil Eye LED
 Drivers (if applicable)

AIMING YOUR HEADLIGHTS

- Our HIDprojectors headlights are designed with an internal cuttoff shield that will not blind oncoming traffic. In order for this feature to work, you will need to aim your headlights properly.
- Park your vehicle approximately 20-30 feet from a wall and turn on your headlights.
- You will see the cutoff line immediately. Using the diagram rotate your headlights accordingly.





NOT TO SCALE

TO ADAPTER


TO VEHICLE HEADLIGHT PLUG

LED DRIVER

WIRING HARNESS

Dielectric grease is highly recommended on all electronic connections to help prevent corrosion.

Corrosion due to improper installation is not covered under warranty.




RELAY

HEADLIGHT POWER

HIGH BEAM

Need help with your install? Email: support@hidprojectors.com Call: 716.662.3479 Monday-Friday | 9a-5p ET

Find installation videos at youtube.com/HIDprojectors



Devil Eye Use

Devil Eye must be OFF when headlights are in use. Running the Devil Eye at the same time as the low beam may result in premature failure to the LED on the Devil Eye. Connecting the white wire on the devil eye to the low beam of your headlights will automatically turn off the devil eye when the headlights are powered on.

Angel Eyes / Halos

Connection to Headlights

Each LED driver must be attached to the matching labeled connector to avoid possible damage. Each connector is color coded for ease of use.

Blue Connector: Front Angel Eye

Green Connector: Rear Angel Eye

Orange Connector: Halo

Connection To Power Source

When connecting to a 12V switched power source, we recommend a switch panel or toggle switch.

As seen in the magnified portion of the diagram, each wire can be connected as follows.

Amber: 12V Power, Amber Light, Turn Signal

Red: 12V Power, Bright White Light

Black: Ground