





**USER MANUAL  
MULTI LANGUAGE**




Item 71001 Version 1.0  
Visit [www.trust.com](http://www.trust.com)  
for the latest instructions

REMOTE CONTROL



1




2




3



4



5



6-8





### 1. Installing the battery

1. Open the battery compartment.
2. Fit the supplied 3V CR2032 lithium battery in the battery compartment. Note the plus and minus pole symbols on the holder.
3. Close the battery compartment.

### 2. Channel switch

Slide the channel switch to I, II, III or IV to access 16 different channels (4 x **1 2 3 4**).

### 3. Control 1 Trust SmartHome receiver per channel

To control receivers individually, assign a separate channel (**1 2 3** and **4**) to each receiver. Read the receivers manual for the code learning procedure.

### 4. Control multiple Trust SmartHome receivers per channel

To control several receivers simultaneously, assign the same channel (for example **1**) to those receivers. Read the receivers manual for the code learning procedure.

### 5. Group function

Assign the **G** button to multiple receivers to switch a group of receivers ON/OFF simultaneously (no dimming).

Read the receivers manual for the code learning procedure. The **G** button can always be used, regardless of the channel switch setting (I, II, III or IV).

### 6. Manual operation of a Trust SmartHome on/off receiver

1. Press ON to switch the receiver on.
2. Press OFF to switch the receiver off.

### **7. Manual operation and dimming with a Trust SmartHome transmitter**

1. Press ON once to switch the receiver on.
2. Press ON again to activate the dim-mode. The light will slowly dim up and down.
3. Press ON a third time to set the desired light intensity.
4. Press OFF to switch the receiver off.


The receiver will return to the last light level when switched on again.

### **8. Manual operation of a Trust SmartHome receiver for electric screens**

1. Send an ON-signal to raise the screen.
2. Send an ON-signal again to stop.
3. Send an OFF-signal to lower the screen.
4. Send an OFF-signal again to stop.

Read the receivers manual to reverse the direction of the screen, if needed.

IMPORTANT INFORMATION  
MULTI LANGUAGE



Item 71001 Version 1.0  
Visit [www.trust.com](http://www.trust.com)  
for the latest instructions

REMOTE CONTROL

Read these simple guidelines. Not following them may be dangerous and faulty installation will invalidate any warranty that may apply to this product.

#### **COMPATIBILITY**

This transmitter works with all Trust SmartHome receivers.


#### **FUNCTIONALITY**

On/off, group function, dim function (only if the receiver is a dimmer) and up/down/stop (electric screens receiver only)

#### **TECHNICAL SPECIFICATIONS**

- Battery 1x 3 V CR2032 lithium
- RF frequency 433.92 MHz
- RF range Up to 30 m indoor/70 m outdoor (optimal conditions)
- Channels 16 + Group on/off

#### **REMARKS**

- Every Trust SmartHome dimmer has a different dimming speed. If possible, use separate channels for each dimmer receiver to avoid non-simultaneous dimming.
- The  button (group function) can only be used to switch receivers on/off. To control dimmer receivers, use channel 1-16 instead.

#### **WIRELESS RADIO SIGNAL**

- The 433.92 MHz radio signal passes through walls, windows and doors.
- Indoor range: up to 30 m. Outdoor range: up to 70 m. (optimal conditions)
- The range is strongly dependent on local conditions, such as the presence of metals. For example, the thin metal coating in Low-emissivity (Low-E) glass has a negative impact on the range of radio signals.
- There may be restrictions on the use of this device outside the EU. If applicable, check whether this device complies with local directives.

#### **LEGAL INFORMATION**

CE: Trust declares this device complies with the Directives as listed in Section 2 of this document.  
WEEE: Dispose of the device at a recycling centre. More information: [www.trust.com](http://www.trust.com)  
Warranty information: [www.trust.com/warranty](http://www.trust.com/warranty)

**BATTERY**

Remove the batteries if the product will not be used for an extended period. Extreme temperatures reduce the capacity and lifetime of the battery.

Replace the battery when the transmit indicator no longer lights when sending an ON or OFF signal or when the reach of the transmitter starts to decrease.

Do not crush, burn or shred batteries. Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste.

**LIFE-SUPPORT**

Never use Trust SmartHome products for life-support systems or other applications in which equipment malfunctions can have life-threatening consequences.

**INTERFERENCE**

All wireless devices may be subject to interference, which could affect performance. The minimum distance between 2 receivers should be at least 50 cm.

**REPAIRING**

Do not attempt to repair this product. There are no user-serviceable parts inside.

**WATER-RESISTANCE**

This product is not water-resistant. Keep it dry. Moisture will corrode the inner electronics.

**CLEANING**

Use a dry cloth to clean this product. Do not use harsh chemicals, cleaning solvents, or strong detergents.

**HANDLING**

Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.

**ENVIRONMENT**

Do not expose the product to excessive heat or cold, as it can damage or shorten the life of electronic circuit boards and batteries.



**CE Declaration of Conformity**

Trust International B.V. declares that this TRUST SMART Home-product:

Model:	AYCT-102 REMOTE CONTROL
Item number:	71001
Intended use:	Indoor

is in compliance with the essential requirements and other relevant provisions of the following directives: EMC Directive (108/2004/EC), Low Voltage Directive (95/2006/EC), ROHS Directive (65/2011/EC), R&TTE Directive (5/1999/EC). The product is compatible with the following norms/standards:

EN 301 489-1 V1.9.2 (2011-09)  
EN 301 489-3 V1.6.1 (2013-06)  
EN 300 220-1 V2.4.1 (2012-05)  
EN 300 220-2 V2.4.1 (2012-05)  
EN 62479:2010  
EN 61000-4-3: 2006+A1: 2008+A2: 2010  
EN 60950-1:2006+A11:2009+A1:2010+A12:2011+A2:2013  
EN 50581:2012

Authorized representative



H. Donker, Procurement Director  
Dordrecht, 06-01-2016

**EUROTEC** People • Technology • Solutions  
HVAC • Refrigeration • Electrical • Measurement

**TRUST INTERNATIONAL B.V.**  
LAAN VAN BARCELONA 600  
3317DD DORDRECHT  
NEDERLAND  
[www.trust.com](http://www.trust.com)