


SINGLE FRONT CARRY POSITION

Please practice safe baby wearing at all times. These instructions are intended to supplement the Owner's Manual by serving as an online reference. For complete instructions—including warnings, limitations of use, and product care—please refer to the Owner's Manual provided with your carrier.



ATTENTION: This carry position is only intended for one child using one carrier. Child must face inward and weigh between 10 lb (4.6 kg) and 40 lb (18.2 kg).

1. Thread the Waist Buckle through the Waist Belt Loops of your Base Carrier. With the warning label touching your stomach, wrap the padded waist and straps around your waist and fasten the buckle; tighten the Waist Belt by pulling the straps to ensure there are no visible gaps. Wrap the Safety Elastic around the Waist Buckle. The carrier should be centered and hanging in front of you with the pocket touching your legs.

2. Bring your child to your chest with legs spread on either side of you. With one hand supporting the child, bring the body of the carrier up over the child's back. With your right hand supporting your child and the carrier, reach for the left shoulder strap with your left hand and place it on your left shoulder.

3. Switch hands to support your child and bring the right shoulder strap in position on your right shoulder. Your child's legs should be equally extended; his bottom should be seated low in the carrier, his head upright and not slumping downward or to the side.

4. Bring both hands behind your neck to buckle and tighten the Chest Strap to ensure shoulder straps are securely positioned on both shoulders.

5. Tighten the shoulder straps by pulling down on the nylon straps. The carrier should be snug enough to provide proper back support for your child. If the carrier is too loose, your child will slump or lean backward. Be careful not to overtighten.