



LTE Cat M1/NB2 GNSS tracker

Standby Time: Without Reporting 480 Hours

Region	Network/Operating Band	GNSS Type	Position Accuracy (CEP)	Certificate
Cat M1:	LTE-FDD:B1/B2/B3/B4/B5/B8/ B12/B13/B18/B19/B20/B25/B26/ B27/B28/B66/B85	u-blox All-in-One GNSS receiver	Autonomous: < 2.5m	FCC, Verizon , IC
Worldwide	Cat NB2: LTE-FDD:B1/B2/B3/B4/B5/B8/ B12/B13/B18/B19/B20/B25/B28/ B66/B71/B85 EGPRS: 850/900/1800/1900MHz			

| 93g (3.28oz)
 | 39.9 × 26.7 × 77.9mm
 1.57"(L) × 1.05"(W) × 3.07"(H)

| -20°C ~ +60°C
 | Li-Polymer, 2600 mAh

- LTE Cat M1/NB2 with 2G Fallback
- Rapid Installation
- Water Resistant
- OTA Control
- Scheduled Report
- Geo-fences
- Motion Detection
- Up to 10,000 Buffer Messages

Installation Guide

1. Fully charge the device using the provided USB cable
2. Power light will blink when charging and solid when fully charged
3. Press and hold power button to turn on and off the device

