


TOOLS NEEDED



- 3MM, AND 5MM ALLEN WRENCHES
- CABLE CUTTERS
- HIGH PRESSURE SHOCK PUMP



WARNING: DO NOT DRILL OR MODIFY YOUR FRAME IN ANY WAY. DOING SO WILL VOID THE WARRANTY. MODIFICATION OF YOUR FRAME IN ANY WAY MAY RESULT IN FRAME FAILURE WHICH MAY RESULT IN SERIOUS INJURY OR DEATH.

PACKAGE INCLUDES

- DROPPER POST
- LOAM LEVER
- HINGED CLAMP
- LEVER BOLT
- SHIFTER CABLE





STEP 1
INSERT CABLE INTO SHIFTER CABLE END BARREL ADAPTER.

CONT'D...


STEP 2

INSERT CABLE WITH BARREL ADAPTER INTO DROPPER POST ACTUATOR ROD.




STEP 3

PULL ACTUATOR ROD AND INSERT CABLE THROUGH SLOT. SET CABLE HOUSING INTO THE BOTTOM HOUSING HOLDER.



STEP 4

INTERNALLY ROUTE CABLE HOUSING THROUGH FRAME ACCORDING TO MANUFACTURER'S RECOMMENDATIONS.





STEP 5

INSERT THE DROPPER POST INTO PROPERLY LUBRICATED SEAT TUBE. BE SURE TO INSERT POST BEYOND MINIMUM INSERTION LINE ON POST.

STEP 6

TIGHTEN SEAT TUBE CLAMP TO THE RECOMMENDED TORQUE SPECIFICATIONS OF YOUR MANUFACTURER.





STEP 7

PLACE SADDLE RAILS INTO CLAMP, ADJUST ANGLE AND FORE/AFT POSITION PER BIKE FIT, TIGHTEN BOLTS WITH 5MM ALLEN WRENCH TO 8-10NM.

LOAM LEVER INSTALL

STEP 1

POSITION HINGED CLAMP ON BAR AND ATTACH LEVER TO CLAMP USING EITHER THREADED HOLE ON LEVER BODY TO BEST FIT YOUR HAND. TIGHTEN WITH 3MM ALLEN WRENCH TO MAXIMUM 2NM. NOTE: THIS POSITION CAN BE CHANGED AFTER INSTALL TO FINE TUNE FIT.





STEP 2

LOOSEN BUT DO NOT REMOVE THE CABLE FIXING BOLT ON THE UNDERSIDE OF THE DROPPER LEVER WITH A 3MM ALLEN WRENCH, SCREW THE BARREL ADJUSTER FULLY IN CLOCKWISE, AND MAKE SURE THE CABLE HOUSING HAS A HOUSING END INSTALLED. INSERT THE DROPPER CABLE THROUGH THE BARREL ADJUSTER UNTIL THE HOUSING IS COMPLETED SEATED IN BARREL ADJUSTER, THREADING THE CABLE UNDER THE CABLE FIXING BOLT AND WASHER.

STEP 3

PULL CABLE TAUT AND TORQUE CABLE FIXING BOLT TO 2.5 NM WITH A 3MM ALLEN WRENCH. NOTE: MAKE SURE CABLE IS SEATED IN MACHINED GROOVE TO ENSURE PROPER CABLE RETENTION WITH THE WASHER.







STEP 4

PUSH THE LEVER 5-10 TIMES TO MAKE SURE THE CABLE HOUSING IS FULLY SEATED AND TO CHECK FOR PLAY IN THE CABLE. NOTE: IF THERE IS PLAY IN THE LEVER/CABLE, LOOSEN CABLE FIXING BOLT WITH 3MM ALLEN WRENCH AND PULL CABLE TIGHT A SECOND TIME. FOR MICRO ADJUSTMENT, USE THE BARREL ADJUST ON THE LEVER WHERE THE CABLE ENTERS.

STEP 5

TRIM EXCESS CABLE WITH CABLE CUTTERS WITH ENOUGH ROOM TO PLACE CABLE END, APPROXIMATELY 10MM. IT IS IMPORTANT TO USE PROPER CABLE CUTTERS TO PREVENT THE CABLE FROM FRAYING.



STEP 6


CRIMP CABLE END IN PLACE.
PUSH LEVER.
DROP POST.
GET RAD.

ADJUSTING REBOUND RATE

THE 30.9MM AND 31.6MM LOAM DROPPER POST FEATURES AN ADJUSTABLE AIR SPRING CARTRIDGE. TO ADJUST HOW QUICKLY THE SEAT POST RETURNS YOU CAN CHANGE THE AIR PRESSURE OF THE MAIN CHAMBER OF THE POST. NOTE: YOU WILL NEED A HIGH PRESSURE SHOCK PUMP.

STEP 1

REMOVE ONE BOLT OF SEAT CLAMP AND REMOVE SEAT FROM POST.



STEP 2

REMOVE RUBBER PLUG TO REVEAL VALVE. USE A COMPATIBLE SHOCK PUMP TO SET PRESSURE BETWEEN 230-300PSI.

WARNING: DO NOT EXCEED 300PSI.

