



TOOLS & MATERIALS NEEDED

- 3MM ALLEN WRENCH
- CABLE CUTTERS
- SHIFT CABLE & HOUSING, FERRULES, AND CABLE END CAP


WARNING: DO NOT DRILL INTO OR MODIFY THE LOAM LEVER IN ANY WAY. DOING SO WILL VOID THE WARRANTY. MODIFICATION OF THE LOAM LEVER IN ANY WAY MAY RESULT IN DAMAGE TO THE LEVER, WHICH MAY RESULT IN SERIOUS INJURY DURING USE.

**PACKAGE INCLUDES**


- LOAM LEVER GEN 2
- 22.2MM HINGED CLAMP W/ MOUNTING BOLT
(OR OTHER CHOSEN ADAPTER)

**STEP 1**

POSITION HINGED CLAMP ON BAR AND ATTACH LEVER TO CLAMP USING ONE OF THE THREE THREADED HOLE OPTIONS ON LEVER BODY TO ACHIEVE YOUR DESIRED POSITION. TIGHTEN WITH 3MM ALLEN WRENCH TO MAXIMUM 2NM. NOTE: THIS POSITION CAN BE CHANGED AFTER INSTALL TO FINE TUNE FIT.



CONT'D...




STEP 2

LOOSEN, BUT DO NOT REMOVE, THE CABLE FIXING BOLT ON THE UNDERSIDE OF THE DROPPER LEVER WITH A 3MM ALLEN WRENCH, SCREW THE BARREL ADJUSTER FULLY IN CLOCK-WISE, AND MAKE SURE THE CABLE HOUSING HAS A HOUSING END INSTALLED. INSERT THE DROPPER CABLE THROUGH THE BARREL ADJUSTER UNTIL THE HOUSING IS COMPLETED SEATED IN BARREL ADJUSTER, THREADING THE CABLE UNDER THE CABLE FIXING BOLT AND WASHER.

STEP 3

PULL CABLE TAUT AND TORQUE CABLE FIXING BOLT TO 2.5 NM WITH A 3MM ALLEN WRENCH.


NOTE: MAKE SURE CABLE IS SEATED UNDERNEATH THE WASHER TO ENSURE PROPER CABLE RETENTION WITH THE WASHER.



STEP 4


PUSH THE LEVER 5-10 TIMES TO MAKE SURE THE CABLE HOUSING IS FULLY SEATED AND TO CHECK FOR PLAY IN THE CABLE.

NOTE: IF THERE IS PLAY IN THE LEVER/CABLE, LOOSEN CABLE FIXING BOLT WITH 3MM ALLEN WRENCH AND PULL CABLE TIGHT A SECOND TIME. FOR MICRO ADJUSTMENTS, USE THE BARREL ADJUSTER ON THE LEVER WHERE THE CABLE ENTERS.




STEP 5

TRIM EXCESS CABLE WITH CABLE CUTTERS WITH ENOUGH ROOM TO PLACE CABLE END ON END OF EXPOSED CABLE (LEAVE AT LEAST 10-15MM FOR THIS). IT IS IMPORTANT TO USE PROPER CABLE CUTTERS TO PREVENT THE CABLE FROM FRAYING.



STEP 6

CRIMP CABLE END IN PLACE. PUSH LEVER. DROP POST. GET RAD.



NEED TO REACH OUT TO OUR TEAM? CONTACT US AT [INFO@PNWCOMPONENTS.COM](mailto:info@pnwcomponents.com).

