

#### FINISH: MILL FINISH ALUMINUM

1/4" (6.4 mm)
COMMERCIAL
SADDLE THRESHOLD

1/4"H x 5"W x 36"L

6.4 mm x 127 mm x 914.4 mm

#### **INSTALLATION INSTRUCTIONS**

- 1. Measure width at the bottom of the frame and cut the threshold to exact full width of the opening.
- 2. If necessary trim and notch the threshold ends to accommodate the side jamb stops.
- 3. Mark and drill pilot holes through the pre-drilled holes in the threshold and fasten with screws provided.
- 4. Seal both ends and along the sides of the threshold.
- 5. Operate the door multiple times to ensure proper adjustment so as not to prevent the door from self-closing and latching.



Meets UL10B, UL10C and UBC 7-2 (1997) Category J





3 HR POSITIVE PRESSURE

MATERIAL FOR USE IN LISTED STEEL FRAMES AND CLASSIFIED HOLLOW METAL STEEL COMPOSITE TYPE FIRE DOORS ARE RATED UP TO AND INCLUDING 3 HOURS, WOOD COMPOSITE TYPE FIRE DOORS ARE RATED UP TO AND INCLUDING 1-1/2 HOURS, AND WOOD CORE FIRE DOORS ARE RATED 20 MINUTES WITHOUT HOSE STREAM.



# PART# CR371536

#### FINISH: DARK BRONZE ANODIZED ALUMINUM

1/4" (6.4 mm)
COMMERCIAL
SADDLE THRESHOLD

1/4"H x 5"W x 36"L

6.4 mm x 127 mm x 914.4 mm

#### **INSTALLATION INSTRUCTIONS**

- 1. Measure width at the bottom of the frame and cut the threshold to exact full width of the opening.
- 2. If necessary trim and notch the threshold ends to accommodate the side jamb stops.
- 3. Mark and drill pilot holes through the pre-drilled holes in the threshold and fasten with screws provided.
- 4. Seal both ends and along the sides of the threshold.
- 5. Operate the door multiple times to ensure proper adjustment so as not to prevent the door from self-closing and latching.



Meets UL10B, UL10C and UBC 7-2 (1997) Category J





3 HR POSITIVE PRESSURE



#### FINISH: MILL FINISH ALUMINUM

1/4" (6.4 mm)
COMMERCIAL
SADDLE THRESHOLD

1/4"H x 5"W x 48"L

6.4 mm x 127 mm x 1219.2 mm

#### **INSTALLATION INSTRUCTIONS**

- 1. Measure width at the bottom of the frame and cut the threshold to exact full width of the opening.
- 2. If necessary trim and notch the threshold ends to accommodate the side jamb stops.
- 3. Mark and drill pilot holes through the pre-drilled holes in the threshold and fasten with screws provided.
- 4. Seal both ends and along the sides of the threshold.
- 5. Operate the door multiple times to ensure proper adjustment so as not to prevent the door from self-closing and latching.



Meets UL10B, UL10C and UBC 7-2 (1997) Category J



3 HR POSITIV

MATERIAL FOR USE IN LISTED STEEL FRAMES AND CLASSIFIED HOLLOW METAL STEEL COMPOSITE TYPE FIRE DOORS ARE RATED UP TO AND INCLUDING 3 HOURS, WOOD COMPOSITE TYPE FIRE DOORS ARE RATED UP TO AND INCLUDING 1-1/2 HOURS, AND WOOD CORE FIRE DOORS ARE RATED 20 MINUTES WITHOUT HOSE STREAM.



# PART# CR371548

FINISH: DARK BRONZE ANODIZED ALUMINUM

1/4" (6.4 mm)
COMMERCIAL
SADDLE THRESHOLD

1/4"H x 5"W x 48"L

6.4 mm x 127 mm x 1219.2 mm

#### **INSTALLATION INSTRUCTIONS**

- 1. Measure width at the bottom of the frame and cut the threshold to exact full width of the opening.
- 2. If necessary trim and notch the threshold ends to accommodate the side jamb stops.
- 3. Mark and drill pilot holes through the pre-drilled holes in the threshold and fasten with screws provided.
- 4. Seal both ends and along the sides of the threshold.
- 5. Operate the door multiple times to ensure proper adjustment so as not to prevent the door from self-closing and latching.



Meets UL10B, UL10C and UBC 7-2 (1997) Category J





3 HR POSITIVE PRESSURE



#### FINISH: MILL FINISH ALUMINUM

1/4" (6.4 mm)
COMMERCIAL
SADDLE THRESHOLD

### 1/4"H x 5"W x 72"L

6.4 mm x 127 mm x 1828.8 mm

#### **INSTALLATION INSTRUCTIONS**

- 1. Measure width at the bottom of the frame and cut the threshold to exact full width of the opening.
- 2. If necessary trim and notch the threshold ends to accommodate the side jamb stops.
- 3. Mark and drill pilot holes through the pre-drilled holes in the threshold and fasten with screws provided.
- 4. Seal both ends and along the sides of the threshold.
- 5. Operate the door multiple times to ensure proper adjustment so as not to prevent the door from self-closing and latching.



Meets UL10B, UL10C and UBC 7-2 (1997) Category J





3 HR POSITIVE PRESSURE

MATERIAL FOR USE IN LISTED STEEL FRAMES AND CLASSIFIED HOLLOW METAL STEEL COMPOSITE TYPE FIRE DOORS ARE RATED UP TO AND INCLUDING 3 HOURS, WOOD COMPOSITE TYPE FIRE DOORS ARE RATED UP TO AND INCLUDING 1-1/2 HOURS, AND WOOD CORE FIRE DOORS ARE RATED 20 MINUTES WITHOUT HOSE STREAM.



# PART# CR371572

FINISH: DARK BRONZE ANODIZED ALUMINUM

1/4" (6.4 mm)
COMMERCIAL
SADDLE THRESHOLD

1/4"H x 5"W x 72"L

6.4 mm x 127 mm x 1828.8 mm

#### **INSTALLATION INSTRUCTIONS**

- 1. Measure width at the bottom of the frame and cut the threshold to exact full width of the opening.
- 2. If necessary trim and notch the threshold ends to accommodate the side jamb stops.
- 3. Mark and drill pilot holes through the pre-drilled holes in the threshold and fasten with screws provided.
- 4. Seal both ends and along the sides of the threshold.
- 5. Operate the door multiple times to ensure proper adjustment so as not to prevent the door from self-closing and latching.



Meets UL10B, UL10C and UBC 7-2 (1997) Category J





3 HR POSITIVE PRESSURE



#### FINISH: MILL FINISH ALUMINUM

1/4" (6.4 mm)
COMMERCIAL
SADDLE THRESHOLD

1/4"H x 5"W x 96"L

6.4 mm x 127 mm x 2438.4 mm

#### **INSTALLATION INSTRUCTIONS**

- 1. Measure width at the bottom of the frame and cut the threshold to exact full width of the opening.
- 2. If necessary trim and notch the threshold ends to accommodate the side jamb stops.
- 3. Mark and drill pilot holes through the pre-drilled holes in the threshold and fasten with screws provided.
- 4. Seal both ends and along the sides of the threshold.
- 5. Operate the door multiple times to ensure proper adjustment so as not to prevent the door from self-closing and latching.



Meets UL10B, UL10C and UBC 7-2 (1997) Category J



3 HR POSITIVI PRESSURI

MATERIAL FOR USE IN LISTED STEEL FRAMES AND CLASSIFIED HOLLOW METAL STEEL COMPOSITE TYPE FIRE DOORS ARE RATED UP TO AND INCLUDING 3 HOURS, WOOD COMPOSITE TYPE FIRE DOORS ARE RATED UP TO AND INCLUDING 1-1/2 HOURS, AND WOOD CORE FIRE DOORS ARE RATED 20 MINUTES WITHOUT HOSE STREAM.



# PART# CR371596

FINISH: DARK BRONZE ANODIZED ALUMINUM

1/4" (6.4 mm)
COMMERCIAL
SADDLE THRESHOLD

1/4"H x 5"W x 96"L

6.4 mm x 127 mm x 2438.4 mm

#### **INSTALLATION INSTRUCTIONS**

- 1. Measure width at the bottom of the frame and cut the threshold to exact full width of the opening.
- 2. If necessary trim and notch the threshold ends to accommodate the side jamb stops.
- 3. Mark and drill pilot holes through the pre-drilled holes in the threshold and fasten with screws provided.
- 4. Seal both ends and along the sides of the threshold.
- 5. Operate the door multiple times to ensure proper adjustment so as not to prevent the door from self-closing and latching.



Meets UL10B, UL10C and UBC 7-2 (1997) Category J





3 HR POSITIVE PRESSURE