# **System Error Codes**

```
Introduction 2-2
Continuable and Non-Continuable Error Codes 2-2
System Error Codes - Explanation 2-2
Accessing the Error Log Utility 2-5
01:10 2-7
01:11 2-7
01:12 2-7
01:13 2-8
02:10 2-8
02:13 2-8
03:10 2-9
04:11 2-9
05:10 Warning (Only applicable to HP DesignJet 800 Series) 2-9
05:11 2-10
08:11 2-10
11:11 2-10
11:13 2-10
12:11 2-11
21:10 2-11
21:11 2-11
22:10 2-11
41:10 2-12
41:13 2-12
42:10 2-12
43:10 2-12
43:11 2-12
56:10 2-13
56:13 2-13
61:04 2-13
61:05 2-14
64:04 2-14
71:04 2-15
71:06 2-15
72:04 2-16
73:04 2-16
79:04 2-17
81:01 2-17
81:11 2-17
85:10 2-18
86:01 2-18
86:11 2-18
86:13 2-19
87:13 2-19
```

93:10 2-19

### Introduction

System error codes are hexa-decimal based numbers generally caused by internal system errors. The following pages contain a list of system error codes and their respective descriptions and recommended corrective actions. Only try one recommended action at a time and check if the error code has disappeared.

### Continuable and Non-Continuable Error Codes

Some of the Error Codes are continuable, which means you can press **Enter** on the front-panel and continue working with the Printer. Non-Continuable Error Codes do not allow you to continue working with the Printer, in this case power the Printer OFF and ON again and see if the System Error disappears. If the Error Code reappears, then the Printer requires an on-site visit in order to resolve the problem.

NOTE

Even though the customer can continue working with a Continuable Error Code, an on-site visit should still be planned to troubleshoot the problem.

### **System Error Codes - Explanation**

System Error Codes consist of 4 digits which explain which component/system is failing and what action should be taken to resolve the problem.

The following table explains the **first** 2 digits of the System Error Code:

Code	Component/System	
01	Main PCA/Electronics Module	
02	Carriage/Carriage PCA	
03	Power Supply Unit	
04	Network Card	
05	Formatter	
06	Hard Disk Drive	
07	Interconnect PCA	
08	Front Panel	
11	Trailing Cable	
12	Carriage Flex Circuit	

Code	Component/System	
17	Interconnect Cable	
21	Service Station	
22	Ink Supply Station	
23	Pressure System (APS)	
24	Ink Delivery System	
25	Spittoon	
31	Cutter	
32	Take-up Reel	
33	Sheet Feeder	
34	Dryer/Blower	
41	Paper-Axis Motor	
42	Scan-Axis Motor	
43	Vacuum Fan	
51	Window Sensor	
52	Drop Detector	
53	Media Sensor	
54	Pinch-Arm Sensor	
55	Line Sensor	
56	Drive Roller Encoder Sensor	
57	Ink Leak Detector	
58	Color Sensor	
59	Media Type Sensor	
61	Language Interpreting	
62	Input/Output through Parallel Port	
63	Input/Output through Network Card	
64	Input/Output through USB Port	
65	Input/Output	
71	Memory Management	
72	Generic Firmware	
73	Servo	
79	Assertion	
81	Media Advance	
82	Media Cut	
83	Single-Sheet Feeding	
84	Roll Feeding	

Code	Component/System
85	Media-Axis Encoder Reading
86	Carriage Movement
87	Scan-Axis Encoder Reading
91	Printhead Firing
92	Servicing
93	Ink Pumping

The following table explains the **last** 2 digits of the System Error Code:

Code	Recovery Action	Response	
00	Replace		
01	Reseat/Reconnect/Clean/Adjust (manually)	5 "1 0	
02	Calibrate/Adjust (using Automatic Process)	Possible for customer to	
03	Power OFF	perform action	
04	Upgrade System Firmware		
05	Upgrade Driver		
06	Add Accessory		
07	Escalate		
08	Send Plot Again		
09	Wrong Part Installed		
10	Replace		
11	Reseat/Reconnect/Clean/Adjust (manually)		
12	Calibrate/Adjust (using Automatic Process)	On-Site	
13	Power OFF	visit	
14	Upgrade System Firmware	required	
15	Upgrade Driver		
16	Add Accessory		
17	Escalate		
18	Send Plot Again		
19	Wrong Part Installed		

### **Error Log Utility**

The Error Log utility contains a record of the last 10 system error codes the Printer has experienced. The purpose of this information is to:


- Determine whether the Printer is experiencing repetitive failures.
- Determine whether the previous problems are causing the current failure in the printer.
- Determine whether there are additional symptoms to the current system error code.

The information that is stored for each error code is:

- The reported System error code.
- The code line in the Firmware where the error was triggered.
- The date when the error code was triggered.

### **Accessing the Error Log Utility**

1 Press the  $\uparrow$  or  $\downarrow$  key until the front panel displays the Setup Menu and then press **Enter**.




2 Press the  $\uparrow$  or  $\downarrow$  key until the front panel highlights Log. Press the Enter key.




3 Press the  $\uparrow$  or  $\downarrow$  key until the front panel highlights **Errors**. Press the **Enter** key.



4 Press the  $\uparrow$  or  $\downarrow$  key until the front panel highlights the error code that you want to see information on. Press the **Enter** key.



5 The front panel displays information on the selected item.



**NOTE** 

To view information on another Error Code, press BACK and the front panel will return to the previous screen

01:10

# Problem Description:

Electronics Module failure. The possible cause could be:

- 1. The Electronics Module is of the wrong type (a 16 MB Electronics Module will not work in a 24" Model).
- 2. Reading, writing or initializing the EEROM failed.
- 3. One of the ASIC's was not found within the Serial Bus that connects the Electronics Module to the Carriage Assembly.
- 4. One of the ASIC's did not respond to the Serial Bus that connects the Electronics Module to the Carriage Assembly.
- 5. The Electronics Module is requesting a move to the Service Station while the previous move is still being completed.
- 6. The Electronics Module Cooling Fan has reached its current limit.

**Corrective Action:** 

Replace the Electronics Module  $\Rightarrow$  Page 8-24.

**System Error:** 

01:11

Problem Description:

The Electronics Module Cooling Fan badly connected.

**Corrective Action:** 

Reconnect the Cooling Fan (located on top of the Electronics Module). If the Cooling Fan continues to fail, check that the connector pins in the Electronics Module are NOT bent.

**System Error:** 

01:12

Problem Description:

The EEROM is not configured correctly (the product number may

be missing).

**Corrective Action:** 

Configure the EEROM correctly using the EEROM setup utility  $\Rightarrow$ 

Page 4-17.

#### 01:13

# Problem Description:

Electronics Module failure. The possible cause could be:

- 1. One of the ASIC's in the Electronics Module is reporting that it is too hot.
- 2. The interruptions from the Scan-Axis servo or from the Paper-Axis servo are not coming as regularly as they are expected or are coming too late.

#### **Corrective Action:**

Try the following:

- Switch the Printer Off and wait a few minutes. Switch the Printer On again and check if the Error Code has disappeared.
- If the Error Code continues, replace the Electronics Module  $\Rightarrow$  Page 8-24.

### **System Error:**

### 02:10

## Problem Description:

Carriage failure. The possible cause could be:

- 1. The Carriage PCA is not compatible with the rest of the Printer.
- 2. The Carriage ASIC has problems initializing.
- 3. The +2.5V reference voltage generated in the Carriage PCA is out of range.
- 4. One of the Carriage ASIC's cannot be found within the Serial Bus that connects the Electronics Module to the Carriage.
- 5. One of the Carriage ASIC's did not respond to the Serial Bus that connects the Electronics Module to the Carriage Assembly.

#### **Corrective Action:**

Replace the Carriage Assembly  $\Rightarrow$  Page 8-78.

### **System Error:**

02:13

### Problem Description:

Carriage failure. The possible cause could be:

1. One of the ASIC's in the Carriage is reporting that it is too hot.

### **Corrective Action:**

- Switch the Printer Off and wait a few minutes. Switch the Printer On again and check if the Error Code has disappeared.
- If the Error Code continues, replace the Carriage Assembly  $\Rightarrow$  Page 8-78.

System Error: 03:10

**Problem** Power Supply failure.

**Description:** 

**Corrective Action:** Replace the Power Supply Unit  $\Rightarrow$  Page 8-27.

System Error: 04:11

**Problem** LAN Card not detected.

**Description:** 

**Corrective Action:** Power OFF the Printer and reconnect the LAN Card.

System Error: 05:09 Error (Only applicable to HP DesignJet 500 and 510

Series)

**Problem** Formatter installed instead of HP-GL/2 Accessory Card.

**Description:** 

Corrective Action: Power OFF the Printer and remove the Formatter and install the HP-

GL/2 Accessory Card  $\Rightarrow$  Page 8-20.

NOTE: If this Error Code appears on a DesignJet 800 Series Printer, then the model number configured in the Printer is incorrect (the Printer thinks it's a DesignJet 500 Series Printer). In this case

reconfigure the model number  $\Rightarrow$  Page 4-17.

System Error: 05:10 Warning (Only applicable to HP DesignJet 800 Series)

**Problem** Formatter not detected.

**Description:** 

**Corrective Action:** Power OFF the Printer and reseat the Formatter.

System Error: 05:10 Error (Only applicable to HP DesignJet 800 Series)

**Problem** Formatter failure.

**Description:** 

Corrective Action: Power OFF the Printer and replace the Formatter  $\Rightarrow$  Page 8-20.

System Error: 05:10 Error (Only applicable to HP DesignJet 500 and 510

Series)

Problem

**Description:** 

HP-GL/2 Accessory Card failure.

Corrective Action: Power OFF the Printer and replace the HP-GL/2 Accessory Card  $\Rightarrow$ 

Page 8-20.

System Error: 05:11

**Problem** Formatter not detected.

**Description:** 

**Corrective Action:** Power OFF the Printer and reconnect the Formatter.

System Error: 08:11

**Problem** Front Panel cannot be detected.

**Description:** 

**Corrective Action:** Reconnect the Front Panel.

System Error: 11:11

**Problem** Trailing Cable badly connected.

**Description:** 

**Corrective Action:** Reconnect the Trailing Cable correctly.

System Error: 11:13

**Problem** Problem with setting the voltage of the Printheads. **Description:** 

**Corrective Action:** Try the following:

■ Check that the Trailing Cable is connected correctly at both ends.

■ Replace the Trailing Cable  $\Rightarrow$  Page 8-40.

■ Replace the Carriage Assembly  $\Rightarrow$  Page 8-78.

12:11

Problem Description:

A short detected in the Carriage Assembly.

**Corrective Action:** 

Try the following:

- Remove ALL the Printheads and clean the flex contacts on the Printheads and in the Carriage Assembly.
- Replace ALL the Printheads.
- Replace the Carriage Assembly  $\Rightarrow$  Page 8-78.

**System Error:** 

21:10

Problem Description:

Service Station failure. The possible cause could be:

- 1. The steps counted by the Service Station motor are not consistent with the expected length of the current movement.
- 2. The Aerosol Fan has reached its maximum current limit.
- 3. The Service Station motor has shutdown because of blockage.

**Corrective Action:** 

Replace the Service Station/Aerosol Fan Assembly  $\Rightarrow$  Page 8-52.

**System Error:** 

21:11

Problem Description:

Service Station cannot be detected or the Service Station is badly adjusted.

**Corrective Action:** 

Try the following:

- Reconnect the Service Station Assembly.
- Reposition the Service Station trip lever.

**System Error:** 

22:10

Problem Description:

Ink Supply Station failure. The possible cause could be:

- 1. Reading, writing or initializing the backup EEROM failed.
- 2. One of the out-of-ink sensors (located in the Ink Supply Station) is not reporting what it should during the initializing process while depressurizing.

**Corrective Action:** 

Replace the Ink Supply Station  $\Rightarrow$  Page 8-48.

System Error: 41:10

Problem

Paper-Axis Motor failure.

Description:

Corrective Action: Replace the Paper-Axis Motor  $\Rightarrow$  Page 8-84.

System Error: 41:13

Problem Description:

Error in the Paper-Axis Motor Encoder quadrature.

Corrective Action: Try the following:

Switch the Printer Off and wait a few minutes. Switch the Printer On again and check if the Error Code has disappeared.

■ If the Error Code continues, replace the Paper-Axis Motor  $\Rightarrow$  Page 8-84.

System Error: 42:10

Problem Description:

Scan-Axis Motor failure.

\_ .....

Corrective Action: Replace the Scan-Axis Motor  $\Rightarrow$  Page 8-29.

System Error: 43:10

Problem

Vacuum Fan failure.

**Description:** 

**Corrective Action:** Replace the Vacuum Fan  $\Rightarrow$  Page 8-64.

System Error: 43:11

Problem
Description:

Vacuum Fan not detected.

\_\_\_\_\_

**Corrective Action:** Reconnect the Vacuum Fan.

56:10

Problem Description:

Drive Roller Encoder Sensor error.

**Corrective Action:** 

Try the following:

- Replace the Drive Roller Encoder Sensor  $\Rightarrow$  Page 8-38.
- If the problem persists, replace the Encoder Disk Assembly.

**System Error:** 

56:13

Problem Description:

Error in the Drive Roller Encoder Sensor quadrature.

**Corrective Action:** 

Try the following:

- Switch the Printer Off and wait a few minutes. Switch the Printer On again and check if the Error Code has disappeared.
- If the Error Code continues, replace the Drive Roller Encoder Sensor ⇒ Page 8-38.

**System Error:** 

61:04

Problem Description:

Firmware Error.

**Corrective Action:** 

- Switch the Printer Off and wait a few minutes. Switch the Printer On again and check if the Error Code has disappeared.
- If the Error Code reappears, check for a new Firmware release.
- If the new Firmware release does not solve the problem, or if new Firmware release was **not** available, then contact the HP Response Center (or directly to the Division) supplying the following information:
  - Model and Serial Number of the Printer.
  - Firmware release of the Printer (use the Printer Information utility  $\Rightarrow$  Page 4-27).
  - The complete Error Code information, including the linefeed where the error occurred (use the Error Log utility to obtain this information ⇒ Page 2-5).

61:05

Problem Description:

Error Processing Job. This Error Code only appears in HP DesignJets 800 Series, or in the HP DesignJet 500 and 510 Series **with** an HP-GL/2 card installed, when processing either a PostScript or HP-GL/2 file.

**Corrective Action:** 

Try the following:

- Switch the Printer Off and wait a few minutes. Switch the Printer On again and resend the file that you were trying to print.
- If the Error Code reappears after resending the file, then try generating the file again and try to print again.
- If the file that is causing this error is PostScript, check if it is Binary. If the file is Binary, use AppleTalk to send the file to the Printer. If AppleTalk is **not** being used to send the Binary file to the Printer, then change the PostScript settings to Binary through the Front Panel (*Set-up menu / PS settings / Encoding / Binary*).
- If the Error Code continues to reappear, check for a new release of the Driver.

**System Error:** 

64:04

Problem Description:

Firmware Error (USB Port).

**Corrective Action:** 

- Switch the Printer Off and wait a few minutes. Switch the Printer On again and check if the Error Code has disappeared.
- If the Error Code reappears, check for a new Firmware release.
- If the new Firmware release does not solve the problem, or if new Firmware release was **not** available, then contact the HP Response Center (or directly to the Division) supplying the following information:
  - Model and Serial Number of the Printer.
  - Firmware release of the Printer (use the Printer Information utility  $\Rightarrow$  Page 4-27).
  - The complete Error Code information, including the linefeed where the error occurred (use the Error Log utility to obtain this information ⇒ Page 2-5).

71:04

Problem Description:

Problem allocating Memory. This Error Code only appears in HP DesignJets 800 Series, or in the HP DesignJet 500 and 510 Series with an HP-GL/2 card installed.

**Corrective Action:** 

Try the following:

- Switch the Printer Off and wait a few minutes. Switch the Printer On again and check if the Error Code has disappeared.
- If the Error Code reappears, check for a new Firmware release.
- If the new Firmware release does not solve the problem, or if new Firmware release was **not** available, then contact the HP Response Center (or directly to the Division) supplying the following information:
  - Model and Serial Number of the Printer.
  - Firmware release of the Printer (use the Printer Information utility  $\Rightarrow$  Page 4-27).
  - The complete Error Code information, including the linefeed where the error occurred (use the Error Log utility to obtain this information  $\Rightarrow$  Page 2-5).

**System Error:** 

71:06

Problem Description:

Out of Memory problem. This Error Code only appears in HP DesignJets 800 Series, or in the HP DesignJet 500 and 510 Series **with** an HP-GL/2 card installed, when processing either a PostScript or HP-GL/2 file.

**Corrective Action:** 

- Look on your computer screen for error messages; some drivers allow you to choose a different printing mode and attempt to send the file again. If necessary, select Send Job as a Bitmap in the driver's Troubleshooting menu (Services tab). This may slow down print speed.
- If the problem persists, you can install extra memory on the HP-GL/2 Accessory Card in your printer.

72:04

Problem Description:

Problem in the Scan-Axis (Firmware Error).

**Corrective Action:** 

Try the following:

- Switch the Printer Off and wait a few minutes. Switch the Printer On again and check if the Error Code has disappeared.
- If the Error Code reappears, check for a new Firmware release.
- If the new Firmware release does not solve the problem, or if new Firmware release was **not** available, then contact the HP Response Center (or directly to the Division) supplying the following information:
  - Model and Serial Number of the Printer.
  - Firmware release of the Printer (use the Printer Information utility ⇒ Page 4-27).
  - The complete Error Code information, including the linefeed where the error occurred (use the Error Log utility to obtain this information ⇒ Page 2-5).

**System Error:** 

73:04

Problem Description:

Servo Error.

**Corrective Action:** 

- Switch the Printer Off and wait a few minutes. Switch the Printer On again and check if the Error Code has disappeared.
- If the Error Code reappears, check for a new Firmware release.
- If the new Firmware release does not solve the problem then replace the Electronics Module  $\Rightarrow$  Page 8-24.
- If the problem continues, contact the HP Response Center (or directly to the Division) supplying the following information:
  - Model and Serial Number of the Printer.
  - Firmware release of the Printer (use the Printer Information utility ⇒ Page 4-27).
  - The complete Error Code information, including the linefeed where the error occurred (use the Error Log utility to obtain this information  $\Rightarrow$  Page 2-5).

79:04

Problem Description:

Firmware Error.

**Corrective Action:** 

Try the following:

- Switch the Printer Off and wait a few minutes. Switch the Printer On again and check if the Error Code has disappeared.
- If the Error Code reappears, check for a new Firmware release.
- If the new Firmware release does not solve the problem, or if new Firmware release was **not** available, then contact the HP Response Center (or directly to the Division) supplying the following information:
  - Model and Serial Number of the Printer.
  - Firmware release of the Printer (use the Printer Information utility  $\Rightarrow$  Page 4-27).
  - The complete Error Code information, including the linefeed where the error occurred (use the Error Log utility to obtain this information ⇒ Page 2-5).

**System Error:** 

81:01

Problem Description:

Paper-Axis shutdown.

**Corrective Action:** 

If this error code appeared but was NOT caused by a paper jam, then try the following:

- Perform the Paper Advance Test  $\Rightarrow$  Page 4-11.
- If the problem persists, replace the Encoder Disk Assembly.

**System Error:** 

81:11

Problem Description:

Paper-Axis shutdown (during the Paper Advance test).

**Corrective Action:** 

Refer to Error Code 81:01.

85:10

Problem Description:

Paper-Axis Encoder error. The Drive Roller Encoder Sensor cannot find the zero position of the Encoder Disk.

**Corrective Action:** 

Try the following:

- Replace the Drive Roller Encoder Sensor  $\Rightarrow$  Page 8-38.
- If the Error Code continues, replace the Drive Roller ⇒ Page 8-86.

**System Error:** 

86:01

Problem Description:

Carriage-Axis shutdown.

**Corrective Action:** 

If this error code appeared but was NOT caused by a paper jam, then try the following:

- Too much friction in the Slider Rod. Enter the Printer Information utility (⇒ Page 4-27) and check the Scan-Axis usage. If the percentage is close to 100%, then lubricate the Slider Rod.
- The Carriage is bumping into the Service Station. If the carriage is stuck at the right hand side of the Printer and cannot be moved out to the center of the Print Platen it is because the Service Station cannot uncap the Printheads. In this case replace the Service Station/Aerosol Fan Assembly ⇒ Page 8-52.
- Perform the Carriage Movement test  $\Rightarrow$  Page 4-8.

**System Error:** 

86:11

Problem Description:

Carriage-Axis shutdown (during the Carriage Movement test).

**Corrective Action:** 

Refer to Error Code 86:01.

86:13

Problem Description:

Carriage-Axis shutdown (Firmware Error).

**Corrective Action:** 

Try the following:

- Switch the Printer Off and wait a few minutes. Switch the Printer On again and check if the Error Code has disappeared.
- If the Error Code reappears, check for a new Firmware release.
- If the new Firmware release does not solve the problem, or if new Firmware release was **not** available, contact the HP Response Center (or directly to the Division) supplying the following information:
  - Model and Serial Number of the Printer.
  - Firmware release of the Printer (use the Printer Information utility  $\Rightarrow$  Page 4-27).
  - The complete Error Code information, including the linefeed where the error occurred (use the Error Log utility to obtain this information ⇒ Page 2-5).

**System Error:** 

87:13

Problem Description:

Unable to read the Carriage Encoder Sensor.

**Corrective Action:** 

Try the following:

- Switch the Printer Off and wait a few minutes. Switch the Printer On again and check if the Error Code has disappeared.
- If the Error Code continues, replace the Carriage Assembly  $\Rightarrow$  Page 8-78 or the Encoder Strip  $\Rightarrow$  Page 8-76.

**System Error:** 

93:10

Problem Description:

Ink System startup failed (also see Page 1-8 for more information).

**Corrective Action:** 

- Check for a leak in the Printer. If a leak is evident (there is ink on Printer components), replace the Ink Supply Tubes  $\Rightarrow$  Page 8-60.
- Perform the Prime Tubes utility (Refer to Page 4-24) and check how long it takes to complete the procedure. If it takes too long to complete the procedure and there is no leak in the Printer, then replace the Ink Cartridges. If it takes a short time to complete the procedure, then replace the Ink Supply Tubes  $\Rightarrow$  Page 8-60.