

TWILIGHT SWITCH FOR LED LIGHTING

user manual

SAFETY RULES



Do not connect the device to loads exceeding the permitted



Connect only in accordance with the diagram presented in the manual. Improper connections may be dangerous, it can damage the controller, and loss of the warranty.





DANGER! Risk of electric shock! Even with the device turned o, the outputs may be live. All assembly work should be ALWAYS performed with the disconnected power circuit.



Connecting the device to a power supply that does not meet the quality requirements specied in EN 50081-1, EN 50082-1, UL508, EN 60950 will invalidate the warranty.

WIRING DIAGRAM







- Before installing the controller, disconnect the voltage in the supplied circuit. Remember that all assembly work should be carried out with the power supply disconnected.
- The controller should be mounted in a place protected from adverse environmental conditions, protected from access by third parties. It is advisable that the device is mounted in a stable and stationary position.
- Familiarize yourself with the diagram and then proceed with the assembly of the controller. Pay special attention to the designation of the controller connectors. Start by connecting the power wires: (+) (red or black with a white dotted line) and (-) (black).
- Connect (pay attention to the polarity) the LED strip. Mount the device in the target place using e.g. double-sided adhesive tape. The light sensor is located on the bottom of the device.
- Connect the device to the power supply and check if it works properly

TECHNICAL SPECIFICATIONS

supply voltage	12 - 24V DC
maximum power	60 - 120 W
maximum current	5 A
energy consumption	< 0,1 W
sensor	optical, twilight
calibration	automatic
dimensions	23 x 17 x 22 mm (0.906 " x 0.669 " x 0.866 ")
protection level	IP20
mounting method	In the housing of another device, in the installation box.
connection method	screw joint
housing	made of polyurethane composition not containing halogens, self-extinguishing for thermal class B (130 °C)
controller operating temperature	From -20°C to +50°C

DISTRIBUTED BY

Wired4Signs USA, LLC 7669 Clinton Highway Powell, TN 37849

Email: info@w4susa.com Phone: +1 (865) 339-4956



made in europe





