



CASAMBI



## FEATURES

- ◆ DIMMER LED CASAMBI
- ◆ Built-in DimmerLed with constant current outputs for dimmable LEDs
- ◆ Power Supply: 12-24-48 Vdc
- ◆ Output current for common anode led modules
- ◆ WHITE, MONOCOLOR, DYNAMIC WHITE, RGB and RGB+W Light Control
- ◆ Command: CASAMBI APP
- ◆ Local Command: N°2 Button Normally Open
- ◆ Current output for R-L-C Loads
- ◆ Adjustable output current between 150-900mA via CASAMBI APP
- ◆ Minimum brightness level: down to 1%
- ◆ PWM Modulation
- ◆ PWM Frequency [3400Hz](#)
- ◆ [Linear](#) curve
- ◆ Soft start and soft stop
- ◆ Soft dimming of brightness
- ◆ Extended temperature range
- ◆ 100% Functional Test

## PRODUCT DESCRIPTION

The LINE-4CC-CASAMBI is a 4-channel output dimmer LED, controllable via Bluetooth thanks to the Casambi APP or locally through two normally open buttons.

The dimmer LED is suitable for driving loads such as Spot-Light and LED modules, White, monochromatic colour, Dynamic White, RGB and RGB+W at constant current. You can connect a power supply at 12-24-48 Vdc.

The maximum value of the output current is from 150mA and 900mA.

The dimmer LED has the following protections: over-power protection, under-power protection, reverse polarity protection and input fuse protection.

The LINE-4CC-CASAMBI enables you to make not only simple brightness adjustments but also more intricate lighting control systems. This is made possible through the creation of multiple scenarios, animations, timers, daylight controls, and more.

The CASAMBI APP can be downloaded for free from the Apple App Store and the Google Play Store.

→ For the regularly updated manual, consult our website: [www.dalcnet.com](http://www.dalcnet.com) or QR Code

→ For the correct functioning of the CASAMBI APP, consult the forum on the Casambi website:

<https://support.casambi.com/support/home>



## PRODUCT CODE

CODE	SUPPLY VOLTAGE	LED OUTPUT	N° OF CHANNELS	TYPE OF COMMAND
LINE-4CC-CASAMBI	12-24-48 VDC	4 x 350 ÷ 900 <sup>1</sup>	4	APP CASAMBI N°2 Push N.A.

## PROTECTIONS

<b>OVP</b>	Over voltage protection <sup>2</sup>	✓
<b>UVP</b>	Under voltage protection <sup>2</sup>	✓
<b>RVP</b>	Reverse polarity protection <sup>2</sup>	✓
<b>IFP</b>	Input fuse protection <sup>2</sup>	✓

## REFERENCE STANDARDS

<b>EN 55015</b>	Limits and methods of measurement of radio disturbance characteristics of electrical lighting and similar equipment
<b>EN 61547</b>	Equipment for general lighting purposes – EMC immunity requirement
<b>EN 61347-1</b>	Lamp Control gear – Part 1: General and safety requirement
<b>EN 61347-2-13</b>	Lamp Control gear – Part 2-13: Particular requirement for d.c. or a.c. supplied electronic Control gear for LED modules

<sup>1</sup> The maximum output current depends on the operating conditions and the ambient temperature of the installation. For the correct configuration, check the maximum deliverable power in the "[Technical Specifications](#)" section and the "[Operating Window](#)".

<sup>2</sup> Protections refer to the control logic of the board.

## TYPES OF PROFILES

NAME OF PROFILE	#PROFILE	DESCRIPTION
<b>LINE 4xDIM 350mA</b>	22990	N°4 LED output channels, four slides to dim the outputs. PWM frequency = 3400Hz. Linear dimming curve. PWM resolution 1176step. Current range adjustable by APP: 150-350mA.
<b>LINE 4xDIM 500mA</b>	22988	N°4 LED output channels, four slides to dim the outputs. PWM frequency = 3400Hz. Linear dimming curve. PWM resolution 1176step. Current range adjustable by APP: 400-500mA.
<b>LINE 4xDIM 700mA</b>	29791	N°4 LED output channels, four slides to dim the outputs. PWM frequency = 3400Hz. Linear dimming curve. PWM resolution 1176step. Current range adjustable by APP: 550-700mA.
<b>LINE 4xDIM 900mA</b>	25655	N°4 LED output channels, four slides to dim the outputs. PWM frequency = 3400Hz. Linear dimming curve. PWM resolution 1176step. Current range adjustable by APP: 750-900mA.
<b>LINE TWxTW 350mA</b>	30786	N°2+2 LED output channels, two slides to dim the outputs and two slides to vary the Colour Temperature. PWM frequency = 3400Hz. Linear dimming curve. PWM resolution 1176step. Current range adjustable by APP: 150-350mA.
<b>LINE TWxTW 500mA</b>	30787	N°2+2 LED output channels, two slides to dim the outputs and two slides to vary the Colour Temperature PWM frequency = 3400Hz. Linear dimming curve. PWM resolution 1176step. Current range adjustable by APP: 400-500mA.
<b>LINE TWxTW 700mA</b>	30788	N°2+2 LED output channels, two slides to dim the outputs and two slides to vary the Colour Temperature. PWM frequency = 3400Hz. Linear dimming curve. PWM resolution 1176step. Current range adjustable by APP: 550-700mA.
<b>LINE TWxTW 900mA</b>	30789	N°2+2 LED output channels, two slides to dim the outputs and two slides to vary the Colour Temperature. PWM frequency = 3400Hz. Linear dimming curve. PWM resolution 1176step. Current range adjustable by APP: 750-900mA.



<b>LINE RGB 350mA</b>	30790	N°3 Output channels for RGB LEDs. PWM frequency = 3400Hz. Linear dimming curve. PWM resolution 1176step. Current range adjustable by APP: 150-350mA.
<b>LINE RGB 500mA</b>	30791	N°3 Output channels for RGB LEDs. PWM frequency = 3400Hz. Linear dimming curve. PWM resolution 1176step. Current range adjustable by APP: 400-500mA.
<b>LINE RGB 700mA</b>	30792	N°3 Output channels for RGB LEDs. PWM frequency = 3400Hz. Linear dimming curve. PWM resolution 1176step. Current range adjustable by APP: 550-700mA.
<b>LINE RGB 900mA</b>	30793	N°3 Output channels for RGB LEDs. PWM frequency = 3400Hz. Linear dimming curve. PWM resolution 1176step. Current range adjustable by APP: 750-900mA.
<b>LINE RGB+W 350mA</b>	30794 Default	N°3+1 Output channels for LEDs. RGB and White can be dimmed separately. PWM frequency = 3400Hz. Linear dimming curve. PWM resolution 1176step. Current range adjustable by APP: 150-350mA.
<b>LINE RGB+W 500mA</b>	30795	N°3+1 Output channels for LEDs. RGB and White can be dimmed separately. PWM frequency = 3400Hz. Linear dimming curve. PWM resolution 1176step. Current range adjustable by APP: 400-500mA.
<b>LINE RGB+W 700mA</b>	30796	N°3+1 Output channels for LEDs. RGB and White can be dimmed separately. PWM frequency = 3400Hz. Linear dimming curve. PWM resolution 1176step. Current range adjustable by APP: 550-700mA.
<b>LINE RGB+W 900mA</b>	30797	N°3+1 Output channels for LEDs. RGB and White can be dimmed separately. PWM frequency = 3400Hz. Linear dimming curve. PWM resolution 1176step. Current range adjustable by APP: 750-900mA.

## TECHNICAL SPECIFICATIONS

		LINE 4CC CASAMBI							
<b>Supply voltage</b>		DC Min: 12 ÷ 48Vdc ± 10%							
<b>Output voltage</b>		Min: Vin/4 – Max: Vin-0,9V (max Vf=43V)							
<b>Input current</b>		Max 3,2A							
<b>Output current<sup>3</sup></b>		@ch							
		4x max 900mA							
<b>Nominal power for channel<sup>3</sup></b>	<b>Current [mA] ± 5%</b>	<b>150</b>	<b>200</b>	<b>250</b>	<b>300</b>	<b>350</b>	<b>400</b>	<b>450</b>	<b>500</b>
	@12 Vdc	1,8W	2,4W	3W	3,6W	4,2W	4,8W	5,4W	6W
	@24 Vdc	3,6W	4,8W	6W	7,2W	8,4W	9,6W	10,8W	12W
	@48 Vdc	7,2W	9,6W	12W	14,4W	16,8W	19,2W	21,6W	24W
	<b>Current [mA] ± 5%</b>	<b>550</b>	<b>600</b>	<b>650</b>	<b>700</b>	<b>750</b>	<b>800</b>	<b>850</b>	<b>900</b>
	@12 Vdc	6,6W	7,2W	7,8W	8,4W	9W	9,6W	10,2W	10,8W
	@48 Vdc	26,4W	28,8W	31,2W	33,6W	27W	38,4W	40,8W	43,2W
<b>Nominal power total<sup>3</sup></b>	<b>Current [mA] ± 5%</b>	<b>150</b>	<b>200</b>	<b>250</b>	<b>300</b>	<b>350</b>	<b>400</b>	<b>450</b>	<b>500</b>
	@12 Vdc	7,2W	9,6W	12W	14,4W	16,8W	19,2W	21,6W	24W
	@24 Vdc	14,4W	19,2W	24W	28,8W	33,6W	38,4W	43,2W	48W
	@48 Vdc	28,8W	38,4W	48W	57,6W	67,2W	76,8W	86,4W	96W
	<b>Current [mA] ± 5%</b>	<b>550</b>	<b>600</b>	<b>650</b>	<b>700</b>	<b>750</b>	<b>800</b>	<b>850</b>	<b>900</b>
	@12 Vdc	26,4W	28,8W	31,2W	33,6W	36W	38,4W	40,8W	43,2W
	@48 Vdc	105,6W	115,2W	124,8W	134,4W	144W	153,6W	163,2W	172,8W
<b>Power loss in standby mode</b>		< 0,5W							
<b>Type of load</b>		R-L-C							
<b>Dimming curves</b>		Linear							
<b>Dimming range<sup>4</sup></b>		1 – 100%							
<b>Minimum dimming level</b>		1%							
<b>Dimming method</b>		Pulse Width Modulation "PWM"							
<b>PWM Frequency<sup>4</sup></b>		3400 Hz							
<b>PWM Resolution<sup>4</sup></b>		1176 Step							
<b>Operating Frequencies<sup>4</sup></b>		2402 – 2483 MHz							
<b>Maximum output power<sup>4</sup></b>		7dBm							
<b>Storage temperature</b>		Min: -40°C – Max: 60°C							
<b>Ambient temperature, Ta range<sup>3</sup></b>		Min: -10°C – Max: 60°C Min: -10°C – Max: 45°C (only for current from 750 to 900mA)							
<b>Type of connector</b>		Push-In terminals							
<b>Wiring section</b>	Solid Size	0.2 ÷ 1.5mm <sup>2</sup> / 24 ÷ 16 AWG							
	Stranded Size								
<b>Wire strip length</b>		9 ÷ 10 mm							
<b>IP protection grade</b>		IP20							
<b>Casing material</b>		Plastic							
<b>Packaging units (pieces/units)</b>		1pcs							
<b>Mechanical dimensions</b>		186 x 29 x 21 mm							
<b>Packaging dimensions</b>		197 x 34 x 29 mm							
<b>Weight</b>		77g							

<sup>3</sup> For the full range check the "Operating Window" of product.

<sup>4</sup> The parameters are derived from the configuration of the Casambi module.


## WIRING DIAGRAMS

Follow the steps below for product installation as shown in the connection diagram:



- Connect the positive of the LED load to the "L" terminal with the "+" symbol, instead the negatives of the LED load to the terminals "L1", "L2", "L3" and "L4" with the "-" symbol.
- Connect the N.O. push button to the "INPUT 1" and "INPUT 2" terminals with the "↗↘" symbol. Be sure not to connect live parts to "INPUT" terminals.
- Connect a 12-24-48 Vdc constant voltage SELV power supply (properly sized power, depending on the technical characteristics of LED load) to the DC IN terminal block with the "+" and "-" symbols. Be sure not to use constant current LED Driver and check that the polarity of the cables is correct.

Like any other product with Bluetooth control, be sure not to place the product inside a metal case or placed near large metal structures. The metal will significantly obstruct the radio signal, which is crucial for the proper functioning of the device.

### → CONNECTION SCHEME PROFILE: LINE 4XDIM





### → CONNECTION SCHEME PROFILE: LINE TW+TW







Made in Italy

→ **CONNECTION SCHEME PROFILE: LINE RGB**



→ **CONNECTION SCHEME PROFILE: LINE RGB+W**



**OBSERVATION:**


Depending on the type and size of the LED modules, it is possible to divide the LED load power supply on the 2 "L+" output terminals.

## CURRENT OUTPUT CONFIGURATION

The LINE 4CC CASAMBI allows to set the maximum current of its 4 output channels, via CASAMBI APP.


As it is possible to see from the following graphs, once established which type of load it wants to connect to the product, whether: White, Dynamic White, RGB or RGB+W. It is possible to load the desired Fixture with the most appropriate current range for the technical characteristics of the load and set the maximum current that can be supplied by the device according to how the system has been configured.

### SETTINGS OF FIXTURE




1. Power on the device and open the CASAMBI APP.


2. Select the "Nearby Device".




3. Tap on the icon of the device, and tap on "Change profile".




4. Select the desired profile.




5. Click "Start update".



6. Wait for the profile to load correctly.



7. Once it has inserted the device inside the Casambi Network, click two times on the product icon.



8. Inside of the device configuration, a function bar will appear where it can set the desired current.




## CURRENT CONFIGURATION BY CASAMBI APP


Example: RANGE 150-350 [mA]




Maximum current that can be supplied by the device for each single output: 350mA




Maximum current that can be supplied by the device for each single output: 300mA



Maximum current that can be supplied by the device for each single output: 250mA



Maximum current that can be supplied by the device for each single output: 200mA



Maximum current that can be supplied by the device for each single output: 150mA

There are 3 range of current configuration:

- RANGE 150-350 [mA] → Settable currents 150 – 200 – 250 – 300 – 350 [mA]
- RANGE 400-500 [mA] → Settable currents 400 – 450 – 500 [mA]
- RANGE 550-700 [mA] → Settable currents 550 – 600 – 650 – 700 [mA]
- RANGE 750-900 [mA] → Settable currents 750 – 800 – 850 – 900 [mA]

## LOCAL COMMANDS FUNCTIONALITY

### N.O. PUSH BUTTON<sup>5</sup>

N° Button	Function		
1-2	Controls a luminaire	Click Long pressure (>1s)	Tap to turn a luminaire on or off – hold to adjust luminaire brightness
	Controls an element	Click Long pressure (>1s)	Tap to turn a device element on or off – hold to adjust the element value
	Control a group	Click Long pressure (>1s)	Tap to turn a group on or off – hold to adjust brightness
	Control scene	Click Long pressure (>1s)	Tap to turn a scene on or off – hold to adjust scene brightness
	Control all luminaires	Click Long pressure (>1s)	Tap to turn all luminaires on or off – hold to adjust brightness
	Cycles scenes	Click Long pressure (>1s)	Tap to cycle through the list of scenes – hold to adjust current scene brightness
	Active/Standby	Click Long pressure (>1s)	Tap to switch between two scenes – hold to adjust current scene brightness

For all other functions consult the documentation of the CASAMBI APP at:

<https://support.casambi.com/support/home>

## UNPAIR DEVICE FROM THE CASAMBI NETWORK

If the device is already connected to a network for which you don't have the credentials and you wish to associate it with a new network, please follow the instructions provided in the Casambi APP's "Nearby Devices" section.

Once you have selected the unpair function and started the procedure, turn off the main power of the power supply connected to the LINE-4CC-CASAMBI and turn it on again after 1 - 2 seconds.


If the main power supply is switched off and on again quickly, unpair may not be done properly. Repeat the unpair sequence by allowing 1 or 2 more seconds to elapse between the moment you turn off and re-turn on the main power of the power <sup>6</sup>.

A second method to unpair the product is to connect an N.O. push button to an "INPUT" terminal of the LINE-4CC-CASAMBI and during the decoupling procedure press the button.

<sup>5</sup> By default, the N.O. Push button is set as "Control a luminaire" and controls the output of the LINE-4CC-CASAMBI.

<sup>6</sup> The discharge time of the power supply secondary depends on the construction characteristics of the power supply used.

## OPERATING WINDOW




Ambient temperature [Ta]:

- provides a current up to 700mA, with a working temperature range of  $-10^{\circ}\text{C} \div +60^{\circ}\text{C}$ .
- provides a current up to 900mA, with a working temperature range of  $-10^{\circ}\text{C} \div +45^{\circ}\text{C}$ .

These maximum current values can be applied only under proper ventilation conditions.

## FLICKER PERFORMANCE




Thanks to its 3,4kHz dimming frequency, the LINE-4CC-CASAMBI effectively reduces the occurrence of the Flicker phenomenon. Depending on an individual's sensitivity and the nature of their activities, flickering can impact one's well-being, even if the changes in luminance are beyond the threshold detectable by the human eye.

The graph shows the phenomenon of Flickering in function at the frequency, measured throughout the dimming range.






The results show the low-risk zone (yellow) and the no-effect zone (green). Defined by IEEE 1789-2015<sup>7</sup>

<sup>7</sup> Institute of Electrical and Electronics Engineers (IEEE). *IEEE std 1789: Recommended Practices for Modulating Current in High-Brightness LEDs for Mitigating Health Risks to Viewers.*

## DIMMING CURVE



## MECHANICAL DIMENSIONS



## TECHNICAL NOTE


### INSTALLATION

- CAUTION: The product may only be connected and installed by a qualified electrician. All applicable regulations, legislation, and building codes must be observed. Incorrect installation of the product can cause irreparable damage to the product and the connected LEDs.
- Maintenance must be performed only by a qualified electrician in compliance with current regulations.  
Pay attention when connecting the LEDs: polarity reversal results in no light output and often damages the LEDs.
- The product is designed and intended to operate LED loads only. Powering non-LED loads may push the product outside its specified design limits and is, therefore, not covered by any warranty.  
Operating conditions of the product may never exceed the specifications as per the product datasheet.
- The product must be installed inside a switchgear/controlgear cabinet and/or junction box protection against overvoltage.
- The product must be installed in a vertical or horizontal position with the label/top cover facing upwards or vertically. Other positions are not permitted. The bottom position is not permitted (label/top cover facing down).
- Keep separated 230Vac (LV) circuits and not SELV circuit from safety extra low voltage (SELV) circuit and from any connection with this product. It is absolutely forbidden to connect, for any reason whatsoever, directly or indirectly, the 230Vac mains voltage to the product (terminal block of BUS included).
- The product must be dissipated correctly.
- The use of the product in harsh environments could limit the output power.
- For built-in components inside luminaires, the ta ambient temperature range is a guideline given for the optimum operating environment. However, integrator must always ensure proper thermal management (i.e. correct mounting of the device, air flow etc.) so that the tc point temperature does not exceed the tc maximum limit in any circumstance. Reliable operation and lifetime is only guaranteed if the maximum tc point temperature is not exceeded under the conditions of use.

### POWER SUPPLY

- Only use SELV power supplies with limited current for device power supply, short circuit protection and the power must be dimensioned correctly.  
In the case of power supplies equipped with ground terminals, it is mandatory to connect ALL protective ground points (PE= Protection Earth) to a properly and certified protection earth.
- The connection cables between the very low voltage power source and the product must be properly dimensioned and must be insulated from any wiring or part at non-SELV voltage. Use double insulated cables.
- Dimension the power of the power supply in relation to the load connected to the device. In case the power supply is oversized compared to the maximum absorbed current, insert a protection against over-current between the power supply and the device.
- For the constant current output, the voltage of LED module (VF) must be less than the supply voltage of at least 5V.

### COMMAND

- The length of the cables connecting between the local commands (N.O. Push button or other) and the product must be less than 10m. The cables must be properly dimensioned and must be insulated from any non-SELV wiring or voltage. It is recommended to use double insulated cables, if deemed appropriate also shielded.
- ALL device and control signal connected to the local command "N.O. Push button" with  symbol, they must not supply any type of voltage.

### OUTPUTS

- It is recommended a length of the connecting cables between the product and the LED module less than 10m. The cables must be properly dimensioned and must be insulated from any wiring or circuits at voltage not SELV. It is recommended to use double insulated cables. In case you want to use connecting cables between the product and the LED module greater than 10m, the installer must guarantee the correct operation of the system. In any case, the connection between the product and the LED module must not exceed 30m.

### ONLY CASAMBI/BLUETOOTH PRODUCT

- WARNING: For optimal functionality of the Casambi signal, do not put the device into metal or aluminium boxes and do not shield the device. As any other Casambi product, should not be placed in a metal enclosure or next to large metal structures. Metal will effectively block all radio signals which are crucial to the operation of the product.

## WARNINGS

- To guarantee the best performances and the full use of functions, make sure to download on your device the last release of CASAMBI APP.
- Whenever CASAMBI APP requires an upgrade of the profile installed in the LED Dimmers, follow the instruction to do it. This allows you to stay always up to date and benefit of new functions released.
- Functionality test are done on all dimmers to ensure the right working. In case the device is still paired to "Dalcnet network", you are asked to unpair it by following the instructions on CASAMBI APP and in paragraph ["UNPAIR DEVICE FROM THE CASAMBI NETWORK"](#).