





	Name	Qty.
1	Combined backrest	1
2	Support plate	4
3	Combined bed box pane	1







1: The 6,7,8,9 are connected by ③ and ④ to 5.
 The 19 connected by ③ and ② to 6, 7 and 2.
 The 5 connected by ③ and ② to 2.




2: ⑫ fixed to the 1,2,4,5 6,7,8,9, with ⑨.




3: The 2,6,7,8,9 are connected by ②, ③ to 1 and 4.
 The 1 and 4 are connected by ③, ⑩ and fixed 3.




4: The ⑪ connected by ⑨ to 1 and 4.
 The ⑪ is only fixed to the lower two self-tapping nails, and the distance between the upper surface of the ⑪ and the lower end of the plate is 16mm.
 Then put the 15 and 16



6: The 13 connected by ⑦ to 14.
 The 10 connected by ⑦ to 11 and 12.




5: The 17 connected by ⑤, ⑥, ⑭ to 1 and 4.
 Then tighten the nut use ⑮.




7: The 17 connected by ⑤, ⑥, ⑭ to 10.
 Then tighten the nut use ⑮.


In order to prevent the left and right long bedside edge damage, only fixed side
Three self-tapping nails, two self-tapping nails near the edge of the plate are not fixed



- 8: First use the ⑧ fix the 18 to the bed box panel.
Second, use ⑧ connect the 18 on the 1 and 4.


















- 9: Paste the ⑬ on the exposed fastener hole.
Cover the air vent with ①.
Cover the 10 and 13, then installation is complete.



Itme	Name	Spec.	Qty
1	Combined left long bedside	1980X380	1
2	Combined rear bedside	1420X380	1
3	Tail moulding	380X43	2
4	Combined right long bedside	1980X380	1
5	Combined middle bed frame plate	1965X380	1
6	Combined left rear short frame plate	702X380	1
7	Combined right rear short frame plate	702X380	1
8	Combined left front short frame plate	702X380	1
9	Combined right front short frame plate	702X380	1
10	Rear bed plank	1540X1212	1
11	Edgings of rear bed plank	1194X45	2
12	Rear bed end strip	1590X45	1
13	Front bed plank	1540X810	1
14	Edgings of front bed plank	810X45	2
15	Front base plate	700X598	2
16	Rear base plate	1144X700	2
17	Hydraulic rod		2
18	Black paint angle cleat		2
19	Pulling strip	1146X116	2

Hardware List

No.	Name	Picture	Qty.	No.	Name	Picture	Qty.	No.	Name	Picture	Qty.
①	15cm air hole		8	⑧	M6 hexagon galvanized nut		14	⑮	17*23 Short angle iron		10
②	Large tapping buckle bar		26	⑨	M4*30 cross countersunk head tapping screw		26	⑯	20 * 20 * 50mm Plastic angle code		24
③	Large buckle wheel		38	⑩	M4*16 cross countersunk head tapping screw		20	⑰	PVC self-adhesive cap		6
④	54mm duplex pull buckle bars (colloid)		4	⑪	M3.5*14 cross countersunk head tapping screw		78	⑱	Dia. 6mm flat washer		14
⑤	M6*25 cross bevelling nickeled screw		14	⑫	Large buckle bar		4	⑲	spanner		1