

Solar Charging Bracket

for Ring Video Doorbell 2nd Generation™



Designed to continuously charge your doorbell using solar energy.

Table of Contents

| Package Includes | 2 |
|--------------------|---|
| Features | 2 |
| Safety Information | 2 |
| Charging Speed | 2 |
| Important Note | 3 |
| Installation | 3 |
| Troubleshooting | 4 |
| Specifications | 5 |

Package Includes

- 1 x Solar charger with micro USB connector
- 1 x Installation screws & wall anchors pack
- 1 x User manual



Features



Extend the battery
life of Ring Video Doorbell
2nd Generation



Powered by solar energy



Weather-resistant

Safety Information

- Do not try to open or break the solar panel.
- · Keep the solar panel away from direct heat sources and fire.
- Ensure that all the screws of the solar panel are tightened before placing it for outdoor use.
- Do not overstretch the USB cable and avoid bending the connector.

Charging Speed

Keep the solar charger exposed to sunlight for a few hours before using it for the first time to charge the Ring Doorbell 2nd Generation.

The charging speed in direct sunlight is approximately 4% every 5 hours. In partial sunlight, it is approximately 2% every 5 hours.




Important Note

The light on Ring Doorbell 2 will flicker blue when connected to our Solar Charger only in the presence of sunlight. This flickering indicates that Doorbell 2nd Generation is being charged.




However, when the solar charger is charging the Doorbell 2nd Generation, this light flickering may NOT HAPPEN every time. At times when there is no light flickering, use your Ring App to check if the battery life has been extended.

Installation



 Remove the back cover from the Ring Doorbell 2nd Generation and dismount it from the wall if you have mounted it previously.




Install the Solar Charger onto the wall using the long screws and wall anchors provided.



Install the mounting bracket of the Doorbell 2nd Generation on to the Solar Charger and screw in.




 Connect the doorbell to the solar charger using the Micro-USB connector.



5. Attach the doorbell to the mounting bracket by following the proper step to insert the doorbell onto its mounting bracket. (if you are not sure, the process is written at the front of the mounting bracket) Make sure you tuck in the Micro-USB connector to avoid any obstruction.



6. Fasten the screw at the bottom of the doorbell.





Troubleshooting

- 1. I am not sure if my Ring Doorbell 2nd Generation is being charged. In the presence of sunlight, there will be a light flickering on Ring Doorbell 2nd Generation to show that it is being charged. However, at other times, it may not flicker. In such cases, please check your Ring App to view the battery status of your Doorbell 2nd Generation.
- 2. It does not charge my Ring Doorbell 2nd Generation.

Please check your Ring App to ensure it's being charged and not just rely on the Ring Light indication. Also, ensure that the Solar Charger is receiving adequate sunlight.

Specification

Dimensions : 6.7 in x 4.83 in x 0.79 in

 Output
 : DC

 Voltage
 : 5V

 Power
 : 0.6W

 Material
 : ABS + PC

Ring Video Doorbell 2nd Generation™ not included. Wasserstein is a trademark of Dropcases Ltd. Ring Video Doorbell 2nd Generation™ is a trademark of Ring, Inc. Wasserstein is not affiliated with Ring, Inc.



For more information, please visit: www.wasserstein-home.com Or contact us at: contact@wasserstein-home.com Made in China