

# ... Now you can really see it!

## Protocol II: Measurement of cellulose content in a sample

This protocol describes how to use  $Carbotrace^{M}$  for tracking cellulose content in a sample.

#### **Solutions and Reagents:**

Carbotrace™ is provided as concentrated solution. The following common reagents are required (not supplied):

- Phosphate buffered saline (PBS), pH 7.4
- 96-well plate (round bottom)
- Spectrophotometer

### **Assay Procedure:**

- Prepare a dilution series of your cellulose containing sample im PBS (e.g.: 1, 1:2, 1:5, 1:10, 1:100, 0)
- Dilute Carbotrace<sup>™</sup> in PBS 1:500.
- Add 50  $\mu l$  of each cellulose containing dilution into a well of a 96-well plate.
- Add 50  $\mu l$  diluted Carbotrace  $^{\scriptscriptstyle \text{M}}$  to each cellulose containing dilution and the blank control.
- Measure emission using spectrophotometer settings (see 'Spectrophotometer Settings' below).

## **Spectrophotometer Settings:**

• Carbotrace<sup>™</sup>680: Excite at 540 nm and collect emission at 680 nm. Optional: Record an emission spectrum (560 - 800 nm) with 540 nm excitation.

Sweden

Org-nr: 559016-7093 VAT-nr: SE 559016709301

**Company Information**