

max3

INSTRUCTION MANUAL

MAX.B Components



Hood



Drool Pads

How to Assemble the Hipseat Carrier

- 1 Connect Zipper A1 and Zipper A2
- 2 Connect Buckle B1 and Buckle B2



How to Assemble Hipseat Carrier zipper



Connect the backrest zipper A1 and the hipseat zipper A2.



make sure zip up to the end.



Turn the zipper handle in the starting direction and press it so that it feels like it's locked.

The lock function prevents the opening during usage.



Connect Buckle B1 and Buckle B2.




Make sure that the zipper and buckle are properly connected.



Hipseat carrier completed.

! Make sure to fasten both the zipper and buckle for safety.

How to Wear Hipseat Carrier



01 Place the hipseat to the back.

02 Breathe in to fasten your waist belt and make sure it is as tight and comfortable as possible.

03 The upper and lower Velcro must be stick to each other perfectly to bear the weight firmly.

04 Lock the buckle and pull the waist belt.

05 Turn the waist belt on the back to the front.

06 Place the baby on the seat.


07 Fasten the buckle on the back of your neck.

08 Check whether the baby is sitting properly.



- Make sure fasten the buckles on the waist belt.
- If you only use Hipseat, please fasten the waist belt tightly to the thinnest part of your waist.
- When using the Hipseat carrier, first place the waist belt on the thin part of the waist, and lower the waist belt slightly toward the pelvis.

Various Uses of Hipseat



Newborn-Hold

Inward-Facing

Forward-Facing

Side-Carry

Forward-Facing
(Hipseat Carrier)

Inward-Facing
(Hipseat Carrier)

Back-Carry
(Hipseat Carrier)

Tips for Hipseat

- When wearing only the hipseat, wear a waist belt on the thin part of waist above the belly button.



- Tighten your waist belt to prevent the hipseat from tilting down.



- To provide better back support for baby, hold baby towards the user so that baby's back is resting against the user's belly.



Tips for Hipseat Carrier

- First tighten your waist belt on the thin waist and lower it a little bit to your pelvis.
If the waist belt is high, it is uncomfortable because the baby's head touches the wearer's face.



- Adjust the width of the shoulder belt depending to the user's body type.



- Buckles that connect both shoulder belts can move up and down.



- Please check if the child is sitting in a comfortable position.



O



X

- Pull forward so that the child's hips don't fall back.



O



X

How to Take off the Waist belt



1 The locked buckles on the waist belt.




2 Unlock the buckles.



3 Take off the waist belt without waking up the asleep baby.

! Place the asleep baby down before taking off the waist belt.

Recommended Usage for each Age



*The usage period of the product may differ according to the growth of the baby.

Use in the Following Circumstances!

When to Use The Hipseat Carrier

- 1 When your baby is too big to use a baby carrier
- 2 When holding a curious baby in kangaroo position for a long time
- 3 When you need both hands free while holding your baby
- 4 When going out for long distances



When to Use The Hipseat

- 1 When your wrist hurts and you need to hold your baby
- 2 Burping the baby after feeding
- 3 When you need to hold your baby indoors for a long time
- 4 When going out for a short distance



How to Authenticate the Genuine Product

Mobile

When registering genuine product via mobile, scan the QR code at the lower part to input serial number and other information.

Cautions in Registering Genuine Product

- 1 Period for Registering Genuine Product : Register within 1 month of receiving the product.
- 2 The authentic certification code cannot be consigned to others.
- 3 The authentic certification code hologram sticker is provided once in purchasing the product, and cannot be reissued when lost or damaged.

QR code



'The serial number tag is attached to the product.'

Notice when connecting the hipseat to the backrest



Turn all zipper handles from the outside to the inside.
The lock function prevents opening during usage.



Connect the hipseat buckle
and the backrest buckle.



Make sure to fasten both the
zipper and buckle for safety.

 **Make sure to fasten both the zipper and buckle for safety.**

How to Tidy the Webbing Straps



1
After Adjusting the length
to your comfort, roll the
webbing straps up to the
position that you want.



2
Hold the rubber band
attached to the webbing
strap.



3
Tighten the rolled
webbing strap using the
rubber band.



4
Completed.

max**B** CAUTION

✔ Cautions in Usage

"IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE"

WARNING - Your balance may be adversely affected by your movement and that of your child

WARNING - Take care when bending or leaning forward or sideways

WARNING - This carrier is not suitable for use during sporting activities. The number and date of the European Standard, i.e. EN 13209-2:2015 A statement that, when using the soft carrier, to monitor your child. A statement that, for low birthweight babies and children with medical conditions, to seek advice from a health professional before using the product. A statement concerning an awareness of hazards in the domestic environment, e.g. heat sources, Spilling of hot drinks, etc

- Pognae Max.B can be used for babies between 3.5kg and 20kgs.
- **Baby can fall through a wide leg opening.**
- Make sure all the buckles and the zippers are connected properly before using.
- **If the buckle or the sewing is damaged before usage, stop usage as there are hazards of accidents.**
- Make sure baby is safely seated in the carrier to avoid the risk of falling.
- Never unbuckle the waist belt while baby is in the carrier.
- Never bend your back forward.
- **Make sure to expose your baby's face, nose, and mouth to avoid suffocation (consistently monitor the baby's condition).**
- **If you press the baby's face tightly on your body, the baby can suffocate.**
- Only use the forward-facing when your baby can control the neck and back perfectly.
- When inexperienced with the usage of a baby carrier, the user can practice on the floor with a cushion or ask another person to help to assist.
- Pognae Max.B is not suitable for sports activities such as running, cycling, and hiking.
- Your hand must protect the baby at all times against hazards that may occur.
- Do not use electric appliances or cook, and never eat hot beverage or food while using the carrier.

✔ Cautions in Washing

Check the contents of the caution before washing.

- Only hand wash (Do not machine wash)
- Make sure to take out the molding foam from the hipseat before washing.
- Wash in cold water.
- Do not dip in water for a long time, and do not wash with hot water or boil the product.
- In drying, avoid UV lights and dry in shades with good air permeability.
- Drying with drum washing machines and dryers may cause shrinking, damages and deformation of the product, so dry in the natural state.
- If alkali substances are included in the baby product detergents, it may be a cause for discoloration and bleaching, so make sure to use neutral detergents.

 IHP2022-007H

