

# max

*Light*

INSTRUCTION MANUAL

## MAX LIGHT Components



# How to Assemble the Baby Carrier(SSC)

- 1 Connect Zipper A1 and Zipper A2
- 2 Connect Zipper B1 and Zipper B2



## How to Assemble the Baby Carrier Type Zipper



Connect the Backrest zipper A1 and the Waist belt zipper A2.



Zip up the Zipper A1 and A2 to the end.



After zipping up the zipper to the end, twist the zipper handle inward until it is locked.

The lock function prevents the opening during usage.



Connect the Zipper B1 and Zipper B2.



Zip up the zipper B1 and B2 to the end.




For completion of the baby carrier, twist the zipper handle inward as the picture above by locking the zipper.

**!** Make sure both sets of zippers must be connected and locked for the baby safety.



POGNAE VIDEO

## How to Wear Baby Carrier



- ⚠️ • Make sure fasten the buckles on the waist belt.
- Place the baby carrier's waist belt on the thin part of the waist, and lower the waist belt slightly toward the pelvis.

## Various Uses of Baby Carrier



Forward-Facing

Inward-Facing


Back-Carry



POGNAE VIDEO

## Tips for Baby Carrier

- To provide maximum back support for your baby, we highly recommend that you wrap the waist belt around your waist, not higher or lower so that the full back panel will be able to wrap around your baby's body. Please refer to the picture below.



- Be careful not to turn your child's legs backward. Adjust the child's hips position so that he can sit in the correct position.



# How to Assemble the Hipseat Carrier

- 1 Connect Zipper A1 and Zipper A2
- 2 Connect Zipper B1 and Zipper B2



## How to Assemble Hipseat Carrier zipper



Connect the Backrest zipper A1 and the Hipseat waist belt zipper A2 to the end.



Zip up the Zipper A1 and A2 to the end.



After zipping up the zipper to the end, twist the zipper handle inward until it is locked.

The lock function prevents the opening during usage.



The hidden Zipper B2 is under the front hipseat cover. Raise the Zipper at the front of the hipseat cover.



The hidden Zipper B1 is inside the front backrest. Raise the zipper cover at the front of the backrest.



Zip up the zipper B1 and B2 to the end.



For completion of the Hipseat carrier, twist the zipper handle inward as the picture above by locking the zipper.


The lock function prevents the opening during usage.

**!** Make sure both sets of zippers must be connected and locked for the baby safety.




POGNAE VIDEO

## How to Wear Hipseat Carrier



- Make sure fasten the buckles on the waist belt.
- If you only use Hipseat, please fasten the waist belt tightly to the thinnest part of your waist.
- When using the Hipseat carrier, first place the waist belt on the thin part of the waist, and lower the waist belt slightly toward the pelvis.

## Various Uses of Hipseat



POGNAE VIDEO

## Tips for Hipseat

- When wearing only the hipseat, wear a waist belt on the thin part of waist above the belly button.



- Tighten your waist belt to prevent the hipseat from tilting down.



- To provide better back support for baby, hold baby towards the user so that baby's back is resting against the user's belly.





## Tips for Hipseat Carrier

- First tighten your waist belt on the thin waist and lower it a little bit to your pelvis.  
If the waist belt is high, it is uncomfortable because the baby's head touches the wearer's face.



- Adjust the width of the shoulder belt depending to the user's body type.





- Buckles that connect both shoulder belts can move up and down.



- Please check if the child is sitting in a comfortable position.



- Pull forward so that the child's hips don't fall back.



## How to control the seat width



With the leg, width widened



Move back the logo cover located at the seat in which the baby is supposed to sit



Fold one wing as the above photo



Fold the remaining wing to fix the two wings with the snap button



Take down the folded logo cover to attach to the Velcro



With the leg, width narrowed

## When should the seat width be adjusted?

Narrowed width	All Positions of Hipseat Carrier			Baby Carrier
	<p>Forward Facing</p>	<p>Inward Facing</p>	<p>Back Carry</p>	<p>Forward Facing</p>
Widened width	Baby Carrier			
	<p>Inward Facing</p>	<p>Back Carry</p>		

💡 Control the seat width according to the above usage posture.  
 Improper adjustment on the seat width may cause discomfort for mommy and baby.

# How to Take off the Waist belt



1 The locked buckles on the waist belt.



2 Unlock the buckles.



3 Take off the waist belt without waking up the asleep baby.

**!** Place the asleep baby down before taking off the waist belt.



POGNAE VIDEO

# Recommended Usage for each Age



\*The usage period of the product may differ according to the growth of the baby.

## Use in the Following Circumstances!

### When to Use The Baby Carrier

- 1 When wanting to form affection through attachment with the baby.
- 2 When it's hard to hold a baby with a sling
- 3 When the mom needs to use the two hands freely
- 4 When going out for long distances
- 5 When holding the baby on the back



### When to Use The Hipseat

- 1 When your wrist hurts and you need to hold your baby
- 2 Burping the baby after feeding
- 3 When you need to hold your baby indoors for a long time
- 4 When going out for a short distance



### When to Use The Hipseat Carrier

- 1 When your baby is too big to use a baby carrier
- 2 When holding a curious baby in kangaroo position for a long time
- 3 When you need both hands free while holding your baby
- 4 When going out for long distances



## Cautions in Connecting the Zipper



Turn all zipper handles from the outside to the inside.  
The lock function prevents opening during usage.

**!** The zipper connection for each type of baby carrier and hipseat carrier must connect the two sets for baby safety.

## How to Tidy the Webbing Straps



After Adjusting the length to your comfort, roll the webbing straps up to the position that you want.



2 Hold the rubber band attached to the webbing strap.



3 Tighten the rolled webbing strap using the rubber band.



4 Completed.



POGNAE VIDEO

# max CAUTION

Light

## ✔ Cautions in Usage

"IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE"

WARNING - Your balance may be adversely affected by your movement and that of your child

WARNING - Take care when bending or leaning forward or sideways

WARNING - This carrier is not suitable for use during sporting activities. The number and date of the European Standard, i.e. EN 13209-2:2015 A statement that, when using the soft carrier, to monitor your child. A statement that, for low birthweight babies and children with medical conditions, to seek advice from a health professional before using the product. A statement concerning an awareness of hazards in the domestic environment, e.g. heat sources, Spilling of hot drinks, etc

- Pognae Max Light can be used for babies between 3.5kg and 20kgs
- **Baby can fall through a wide leg opening.**
- **Make sure all the buckles and the zippers are connected properly before using.**
- **If the buckle or the sewing is damaged before usage, stop usage as there are hazards of accidents.**
- Make sure baby is safely seated in the carrier to avoid the risk of falling.
- Never unbuckle the waist belt while baby is in the carrier.
- Never bend your back forward.
- **Make sure to expose your baby's face, nose, and mouth to avoid suffocation (consistently monitor the baby's condition).**
- **If you press the baby's face tightly on your body, the baby can suffocate.**
- Only use the forward-facing when your baby can control the neck and back perfectly.
- When inexperienced with the usage of a baby carrier, the user can practice on the floor with a cushion or ask another person to help to assist.
- Pognae Max Light is not suitable for sports activities such as running, cycling, and hiking.
- Your hand must protect the baby at all times against hazards that may occur.
- Do not use electric appliances or cook, and never eat hot beverage or food while using the carrier.

## ✔ Cautions in Washing

Check the contents of the caution before washing.

- Only hand wash (Do not machine wash)
- Make sure to take out the molding foam from the hipseat before washing.
- Wash in cold water.
- Do not dip in water for a long time, and do not wash with hot water or boil the product.
- In drying, avoid UV lights and dry in shades with good air permeability.
- Drying with drum washing machines and dryers may cause shrinking, damages and deformation of the product, so dry in the natural state.
- If alkali substances are included in the baby product detergents, it may be a cause for discoloration and bleaching, so make sure to use neutral detergents.



CB161A003-0002

