

2015 Kawasaki Versys 650 Handlebar Risers Installation Instructions

Thank you for purchasing our handlebar risers!

Items included in the kit



Risers



Four M-8 Socket Head Cap Bolts

Tools needed for installation

6 mm Allen (hex) wrench (may be found in your motorcycle toolkit)

1. Place a towel to protect your bike's tank during installation



Attach a piece of masking tape to the front upper part of the top handlebar clamp to mark which way is up.

2. Unscrew the four handlebar screws from the top clamp with the 6 mm Allen wrench, starting with the lower right screw and continue clockwise with the remaining screws.



3. Remove the top part of the clamp and then remove the handlebar from the bottom clamp, as shown



4. Position handlebar risers into the bottom clamp, securing them temporarily with masking tape.



Each riser's outline shape will match up with the bottom part of the handlebar clamp.

5. Next, position the handlebar on top of the risers, so that it stays inside the cutouts of the riser pieces. Then, put the top part of the handlebar clamp on top of the risers and adjust the angle of the handlebar.

6. Starting with the top left, **lightly screw** the two M-8 bolts provided into the top holes with the 6 mm Allen wrench. Then, lightly screw in the bottom bolts.



7. Next, sit on the bike and adjust the handlebar to your liking.

8. Now, starting with the upper screws, tighten up the **M-8 Socket Head Cap bolts** with the 6 mm hex wrench at medium strength, or if you have a torque wrench then tighten it at 25 N/m (2.5 kgf/m), (18 ft/lb). Do the same for the bottom bolts. Remove all of the masking tape pieces.

Installation is now completed.



Moto